
Onan

Engine

Parts Catalog

P224G OL24 LX990



Printed in U.S.A.

965-0266C 2-99 (Spec B-H)

MODEL IDENTIFICATION

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO. and SERIAL NO. from the Onan nameplate.

For handy reference, insert your nameplate information in the spaces below.

MODEL AND SPEC NO.

SERIAL NO.

DIGITAL CONTROL SOFTWARE VERSION

AND DATE (IF APPLICABLE)

SAFETY PRECAUTIONS

The following symbols are used in Onan manuals to alert users to the potentially dangerous conditions relating to maintenance of equipment and replacement of parts. Please read and observe.

▲ DANGER

This symbol warns of immediate hazards which will result in severe personal injury or death.

△WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.

△CAUTION

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or product or property damage.

PRODUCT SAFETY PRECAUTIONS

△WARNING

Service and repair of Onan equipment must be performed by trained, experienced personnel only. Improper service or repair may result in property damage, severe personal injury or death. Do not use this catalog as a guide to servicing your equipment. Read and follow the IMPORTANT SAFETY INSTRUCTIONS in the Service Manual appropriate for the equipment you are working on.

△WARNING

Contact with USED ENGINE OILS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking or changing engine oils take all necessary precautions not to ingest, breathe the fumes or contact the used oil.

△WARNING

Contact with ASBESTOS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When handling engine gaskets take all necessary precautions not to ingest, breathe or contact the dust from the gaskets! Use adequate ventilation and wear protective gloves, masks and clothing!

△WARNING

Contact with BENZINE and LEAD, found in gasoline, fuel additives and solvents has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking, draining or adding gasoline and fuel additives or using solvents take all necessary precautions not to ingest, breathe the fumes or contact the liquids. Use adequate ventilation and wear protective gloves, masks and protective clothing!

Introduction

This parts manual applies to the Performer engine as listed in the Engine Data Table. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Parts illustrations are typical. Throughout this manual, right and left sides are determined by facing the flywheel end (FRONT) of the Engine.

Using the MODEL and SPECIFICATION NUMBER from the nameplate, consult the SALES OPTION CODE TABLE in the back of the book to identify factory installed parts that are unique to your engine. (Note: The diagonal line (/) in the model and specification number separates engine characteristics from the specification number and letter. The specification number denotes customer requested features. The specification letter advances (A to B, B to C, etc.) with major manufacturing changes.)

Engine Data Table

Model	Rating
P224G-I/*	24 Horsepower
OL24/*	24 Horsepower
LX990/*	24 Horsepower

Adapter Assy, Oil Fill, 14 Carburetor, Emissions, 25 Adapter, Bearing Plate, 9 Carburetor, LP, 26 Carburetor, LPG Emissions, 37 Adapter, Clutch, 42 Adapter, Exhaust, 53 Carburetor, Spec B Gasoline (Components), 23 Adapter, Governor Arm, 29 Carburetor, Spec C Gasoline (Components), 24 Adapter, Hydraulic Pump, 9 Carburetor, Begin Spec G (Components), 25 Adapter, Oil Filter, 15 Choke, Manual, 41 Adapter, Oilcap, 14 Clamp, Muffler, 53 Adapter, Remote Air Cleaner, 20 Cleaner, Air, 19 Arm Assy, Governor Control, 29 Cleaner, Remote Air, 21 Arm, Governor, 17 Clip, Choke Cable, 34 Arm, Governor Control, 29 Clip, Lock, 36 Clutch. 42 Ball, Governor, 10 Coil, Battery Ignition, 51 Ball, Governor Shaft Bearing, 17 Control, Ignition, 17 Base, Oil, 13 Converter, LPG, 38 Bearing, Camshaft, 7 Cover, Air Cleaner, 19 Bearing, Connecting Rod Half, 7 Cover, Air Cleaner Element, 19 Bearing, Cylinder Block Flanged Sleeve, 7 Cover, Exhaust Tube, 53 Bearing, Governor Shaft, 17 Cover, Inner Air Cleaner, 19 Bearing, Rear Crankshaft, 7 Cover, Valve Compartment, 7 Block, Cylinder, 7 Crankshaft, 11 Bracket Assembly, Governor, 33 Cup, Governor, 10 Bracket, Cable, 29 Cup, Oil Pump Intake, 13 Bracket, Choke, 36 Bracket, Choke Cable (Front Pull), 34 Decal, Control Panel, 41 Bracket, Choke Cable (Rear Pull), 35 Definitions, Sales Option Code, 62 Bracket, Coil Mounting, 51 Drain, Oil Filter, 15 Bracket, Fill Tube, 14 Elbow, Brass (LP), 26 Bracket, Fuel Line, 29, 33 Elbow, Carburetor Inlet, 43 Bracket, Fuel Tank, 43 Elbow, LOPKO Street, 45 Bracket, Governor, 41 Elbow, LP Converter Kit Brass, 38 Bracket, Governor Adjust, 29, 31 Elbow, Oil Filter Street, 15 Bracket, Governor Control Mounting, 29 Elbow, Remote Air Cleaner Air Inlet, 20, 21 Bracket, Lifting, 29 Element, Air Cleaner, 19 Bracket, LP Converter Kit, 38 Element, Remote Air Cleaner, 21 Bracket, Muffler, 53 Exhaust System, 53 Bracket, Solenoid, 36 Bracket, Two Speed Governor, 33 Filter, Breather Tube, 7 Bracket, Two Speed Governor Solenoid, 33 Filter, Fuel, 54 Bushing, Control Arm, 29 Filter, Oil, 15 Bushing, Governor Control, 29 Filter, Remote Air Cleaner Breather Tube, 20 Bushing, Piston Pin, 7 Fitting, Barbed, 22 Bushing, Two Speed Governor Control, 33 Flywheel, 12 Cable Assy, Two Speed Governor, 33 Gasket, Bearing Plate, 7 Cable, Spark Plug, 51 Gasket, Carburetor, 37 Camshaft, 10 Gasket, Carburetor Mounting, 23 Cap, Breather, 7 Gasket, Carburetor Mounting (Dual Fuel), 27 Cap, Exhaust Valve, 7 Gasket, Carburetor Mounting (LP), 26 Cap, Fuel Fitting, 54 Gasket, Carburetor Mounting (Spec B), 23 Cap, Fuel Tank, 43 Gasket, Carburetor Mounting (Spec C), 24 Cap, Oil Fill, 14 Gasket, Cylinder Head, 7 Cap, Starter Solenoid, 39, 40 Gasket, Exhaust Manifold, 53 Cap, Vacuum Port, 17 Gasket, Intake Manifold, 37 Capacitor, Air Cleaner Adapter Mounted, 19 Gasket, Oil Base, 13 Capacitor, Ignition Coil Bracket Mounted, 51 Gasket, Oil Base Plug, 13 Capacitor, Remote Air Cleaner Mounted, 20

Gasket, Oil Filter, 15 Kit, 4 Pin Harness Connector, 47 Gasket, Oil Filter Adapter, 15 Kit, 4 Wire, 6 Pin Wiring Harness, 47 Gasket, Plate, 9 Kit, 6 Pin Harness Connector, 47 Gasket, Valve Cover, 7 Kit, Air Cleaner, 19, 20 Gear, Camshaft, 10 Kit, Alternator Terminal, 17 Gear, Crankshaft, 11 Kit, Carburetor Repair (Begin Spec G), 25 Gear, Flywheel Ring, 12 Kit, Carburetor Repair (Spec B), 23 Gearcase, 17 Kit, Carburetor Repair (Spec C), 24 Governor, Two Speed, 33 Kit, Choke Lever (Spec B), 23 Grommet, Rubber, 19, 31 Kit, Choke Lever (Spec C), 24 Grommet, Two Speed Governor Fuel Line Bracket, 33 Kit, Choke Shaft (Spec B), 23 Guard, Stationary, 31 Kit, Choke Shaft (Spec C), 24 Guide, Valve, 7 Kit, Clutch, 42 Kit, Complete Engine Gasket, 7 Harness, Control Panel Wiring, 41 Kit, Control Panel, 41 Harness, Control Wiring, 50 Kit, Cylinder Head Removal Gasket, 7 Harness, Engine Wiring, 47, 49 Kit, Electric Fuel Pump, 32 Harness, LOPKO Wiring, 48 Kit, Exhaust Adapter, 53 Head, Cylinder, 7 Kit, Exhaust Cover & Support, 53 Hose, Air Cleaner Breather, 19 Kit, Float (Spec B), 23 Hose, Air Inlet (Dual Fuel), 27 Kit, Float (Spec C), 24 Hose, Air Inlet (LP), 26 Kit, Front /Rear Outlet Muffler, 53 Hose, Breather, 37 Kit, Front Pull Choke, 34 Hose, Breather (Gasoline), 22 Kit, Fuel Cut-off Solenoid (Spec C), 24 Hose, Breather (LP), 26 Kit, Fuel Tank, 43 Hose, Fuel (Dual Fuel), 27 Kit, Gasket, 55 Hose, Fuel (Gasoline), 22 Kit, Left Front Side or Right Rear Side Manifold, 53 Hose, Fuel Pump, 54 Kit, Low Oil Pressure, 45 Hose, LP Fuel, 26 Kit, LPG Conversion, 37 Hose, LPG, 37 Kit, LPG Converter, 38 Hose, Remote Air Cleaner Breather, 20 Kit, Muffler, 53 Housing, Air Cleaner, 19 Kit, Oil Pump Gasket, 9 Housing, Air Cylinder, 29 Kit, Piston Ring, 9 Housing, Blower, 29 Kit, PTO - 1" Shaft, 12 Hub, Governor Cup, 10 Kit, PTO - 7" Pilot Adapter, 9 Kit, PTO Bearing Plate Adapter, 9 Indicator, Oil Fill, 14 Kit, PTO Electric Clutch Adapter, 42 Insert, Valve Seat, 7 Kit, PTO Front Pulley, 12 Insulator, Ignition Module, 17 Kit, PTO Spacer, 12 Kit, Remote Choke, 36 Jet, Idle (Dual Fuel), 27 Kit, Remote Elbow, 21 Jet, Idle (Spec B), 23 Kit, Right Front Side or Left Rear Side Manifold, 53 Jet, Idle (Spec C), 24 Kit, Side Pull Governor, 29 Jet, Main Fuel High Altitude, 25 Kit, Starter Brush, 40 Jet, Power (Spec B), 23 Kit, Starter Bushing, 40 Jet, Power (Spec C), 24 Kit, Starter Cap, 39 Joint, Ball, 31, 36 Kit, Starter Clutch, 40 Kit, Starter Dust Seal, 40 Key. 41 Key, Blower Wheel Machine, 12 Kit, Starter Hardware, 40 Key, Camshaft Gear Woodruff, 10 Kit, Starter Mounting Bracket, 40 Key, Clutch Drive, 42 Kit, Starter Shift Lever, 40 Key, Crankshaft Gear, 11 Kit, Starter Solenoid, 40 Key, Crankshaft Woodruff, 11 Kit, Stationary Grill, 31 Key, Flywheel, 12 Kit, Throttle Shaft (Spec B), 23 Kit, Throttle Shaft (Spec C), 24 Kit, Front Pull Governor, 29 Kit, 2 Speed, Solenoid Governor, 33 Knob, Air Cleaner, 19

Kit, 35 Amp Alternator, 17

Label, Blank Kit Number, 17 Pump, Vacuum Fuel, 54 Label, Blank Kit Number, 9, 12, 19, 20, 21, 38, 41, 47 Rectifier, LOPKO, 50 Label, Kit Number (Emissions), 37 Rectifier, Silicon, 47 Labels, 55 Regulator, Voltage, 17, 29 Laber, Blank Kit Number, 31 Repair Kit, Solenoid Valve, 25 Lever, Choke (Front Pull), 34 Repair Package, Accelerator Pump, 25 Lever, Choke (Remote), 36 Repair Package, Float and Gasket, 25 Lever, Control, 41 Ring, Camshaft Retaining, 10 Lever, Governor, 31 Ring, Crankshaft Retaining, 11 Line, Flex Oil, 15 Ring, Piston Retaining, 9 Line, Fuel, 43 Rod, Choke, 36 Line, Pulse, 54 Rod, Connecting, 9 Link, Choke (Front Pull), 34 Rod, Governor, 31 Link, Choke (Remote), 36 Rod, Governor Control, 22, 31 Link, Governor Control, 29 Rotator, Valve, 7 Lock, Valve Spring, 7 Rotor, Ignition, 51 Manifold, Intake (Gasoline), 22 Sales Option Code Definitions, 62 Manifold, Intake (LP), 26 Sales Option Code Table, 56 Manifold, LH Exhaust, 53 Screen, Breather Tube, 7 Manifold, RH Exhaust, 53 Seal, Breather Cap O'Ring, 7 Mixer, LPG (Dual Fuel), 27 Seal, Crankshaft Oil, 7, 17 Muffler, 53 Seal, Governor Shaft Oil, 17 O'Ring, Oil Fill Cap, 14 Seal, Intake Valve, 7 O-Ring, Oil Fill Adapter, 14 Seal, Oil Fill Adapter, 14 Seal, Oil Fill Tube, 14 Paint, 55 Seal, Remote Air Cleaner O'Ring, 20 Panel Assy, Control, 41 Sealant, Thread, 55 Panel, Control, 41 Shaft, Governor, 17 Pin, Bearing Stop, 7 Shaft, PTO, 12 Pin, Center, 10 Sheet, Instruction, 12, 17, 39, 41, 47 Pin, Choke Swivel Cotter (Front Pull), 34 Shim, Crankshaft Thrust, 7 Pin, Cotter, 29 Shutoff, LP Converter Kit Fuel Solenoid, 38 Pin, Cotter (Two Speed Governor), 33 Solenoid, Fuel Cutoff (Spec B), 23 Pin, Gearcase Alignment, 7 Solenoid, Remote Choke, 36 Pin, Governor Cup Stop Dowel, 17 Solenoid, Two Speed Governor, 33 Pin, Piston, 9 Spacer, Air Cleaner, 19 Piston, 9 Spacer, Air Cleaner (Gasoline), 19 Plate, Air Deflector, 19 Spacer, Air Cleaner (LP), 26 Plate, Ignition Plunger Cover, 9 Spacer, Air Intake, 37 Plate, Rear Bearing, 7 Spacer, Crankshaft, 11 Plug, Black Nylon Stationary Guard, 29 Spacer, PTO, 12 Plug, Blower Housing Hole, 31 Spring, Bypass Valve, 9 Plug, Countersunk (LOPKO), 15 Spring, Governor, 29 Plug, Cylinder Block Core Hole, 7 Spring, Governor, 41 Plug, Cylinder Block Expansion, 7 Spring, Governor (Low Speed), 33 Plug, Expansion, 17, 25 Spring, Governor Rod, 22 Plug, Fuel Tank Drain, 43 Spring, Idle Setting, 29 Plug, Governor Cap, 33 Spring, Valve, 7 Plug, Hole, 20 Starter, 39 Plug, Oil Base, 13 Starter (Components), 40 Plug, Spark, 51 Stator, 17 Plunger, Bypass Valve, 9 Stator, Alternator, 17 Precleaner, Remote Air Cleaner, 21 Strap, Fuel Tank, 43 Pulley, Drive, 12 Support, Air Cleaner, 19 Pump, Fuel, 54 Support, Exhaust Cover, 53

Pump, Oil, 9

Switch, High Temperature Cutoff, 9

Switch, Ignition, 41 Switch, LOPKO, 45

Swivel, Choke Lever (Front Pull), 34

Swivel, Choke Lever (Two Speed), ${\bf 33}$

Swivel, Throttle Lever, **29** System, Gasoline Fuel, **22** System, LP Fuel, **26**

Table, Sales Option Code, 56

Tank, Fuel, **43**Tappet, Valve, **7**

Tube, Air Intake, 19, 37

Tube, Breather (Dual Fuel), 27

Tube, Crankcase Oil, 7

Tube, Cylinder Block Breather, 7

Tube, Exhaust, 53

Tube, Idle Feed (Dual Fuel), 27

Tube, Oil Fill, 14

Tube, Remote Air Cleaner Breather, 20

Tube, Remote Air Cleaner Induction, 21

Tube, Vacuum Port, 17

Valve, Breather, 7

Valve, Exhaust, 7


Valve, Float, 25

Valve, Intake, 7


Valve, Shutoff, 43

Wrapper, Air Cleaner Element, 19

Yoke, Governor Shaft, 17




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1		1	Block, Cylinder (See Short	26			*Guide, Valve
			Block Catalog #932-0109)		110-3167	2	Exhaust
			(Includes Parts Marked *)		110–3168	2	Intake
2	123-0954	1	Cap and Valve, Breather	27	110–0539	4	Spring, Valve
3	123-0952	1	*Tube, Breather	28		_	Lock, Valve Spring
4	123–1417	1	Filter, Breather Tube		110–3572	8	Spec B,C
5	110 1604 01	2	Cover, Valve Compartment	29	110–0639 115–0006	8 4	Spec E
	110–1624–01 110–3616–02	1	Spec B,E Spec C,D	30	115-0000	4	Tappet, Valve Rotator, Valve
	110-3616-62	1	Spec C,D	30	110-0904	2	Spec B,C (Intake)
6	110–3575	2	Gasket, Valve Cover		110-0904	4	Begin Spec E
7	517-0048-01	1	*Plug, Expansion (Plated)	31	800-0011	2	Screw, Cap – Hex Head
8	110-3604	2	Seal, Intake Valve				(1/4–20 x 2")
9	110-2987	2	Gasket, Cylinder Head	32	123-0951	1	Clamp, Loop – Breather Tube
10	110-3549	2	Head, Cylinder				Cap
11	809–0035	1	Screw, Breather Clamp	33	123-0958	2	Screen, Breather Tube
			(#8 x 3/4")	34	509-0117	1	Seal, O-Ring - Breather Cap
12	101 0001		Bearing, Rear Crankshaft	35			Bearing, Half – Connecting Rod
	101–0804 101–0804–02	1	* Standard 1.002" Undersize		114-0188	4	Standard
	101-0804-02		1.010" Undersize		114-0188-02	4	.002" Undersize
	101-0804-20		1.020" Undersize		114-0188-10	4	.010" Undersize
	101-0804-30		1.030" Undersize		114-0188-20	4	.020" Undersize
13	104–0575	2	*Washer, Crankshaft Bearing		114-0188-30	4	.030" Undersize
			Thrust	36	500 0040	0	*Stud, Cylinder Head Mounting
14	101-0809	1	*Gasket, Bearing Plate		520-0919	8	3/8 x 2–19/32" (Install 4
15			Plate, Rear Bearing				Bottom Holes – RH, LH Heads)
	101-0439-01	1	* Code 11AH,11AW		520-0876	4	3/8 x 2–3/4" (Install 2 Top
	101-0430-01	1	SAE-B - Code 11AR		020 0070	•	Holes – RH, LH Heads)
	101-0437-01	1	SAE-A - Code 11AP		520-0918	8	3/8 x 3" (Install 4 Middle
16	101–0793–02 101–0405	1 2	Begin Spec E *Bearing, Camshaft				Holes – RH, LH Heads)
17	509–0041	1	Seal, Crankshaft Oil (Rear)	37			Bearing, Sleeve - Flanged
18	516–0072	4	*Pin, Bearing Stop		101-0805	1	* Standard
19	800-0051-01	5	Screw, Cap – Hex Head		101-0805-02		.002" Undersize
			(3/8–16 x 1–1/4")		101-0805-10		.010" Undersize
			Loctite Patch		101-0805-20	1	.020" Undersize
20	526-0063	2	Washer, Flat – Copper	00	101-0805-30	1	.030" Undersize
<u>.</u> .			(1/4" Screw)	38	104-0776	AR 2	*Shim, Crankshaft Thrust (.005")
21	120-0680	1	*Tube, Crankcase Oil	39 40	516–0141 104–0091	20	*Pin, Gearcase Alignment Nut, Hex (Special)
22	110 0560	0	Valve, Intake	41	114–0036	2	Bushing, Piston Pin
	110–3569 110–1718	2 2	Spec B,C Begin Spec E	42	526-0402	5	Washer, Flat (3/8")
23	110-1710	2	Valve, Exhaust	43	110-3571	2	Cap, Valve – Exhaust (Spec
20	110-3570	2	Spec B,C				B and C only)
	110–1719	2	Begin Spec E	44	526-0250	20	Washer, Flat - Heat Treated
24			Insert, Valve Seat – Exhaust				(3/8" Screw)
	110–1716	2	* Standard	45	851–0029	24	Washer, Compression (Special)
	110-1716-02	2	.002" Oversize	46	517–0067	1	Plug, Core Hole
	110–1716–05	2	.005" Oversize	47	160 0100	4	Kit, Gasket Cylinder Head Removal
	110-1716-10	2	.010" Oversize		168–0190 168–0191	1 1	Complete Engine
	110-1716-25	2 2	.025" Oversize	48	110–0893	2	Washer, Exhaust Valve Spring
25	110–3655–25	2	.025" Oversize	10	110 0000	_	Retainer (Spec B and C only)
25			Insert, Valve Seat – Intake (Zinc Plated)	49	800-0007	2	Screw, Cap – Hex Head
	110–3655	2	* Standard				(1/4–20 x 1")
	110–3655–02	2	.002" Oversize				
	110-3655-05	2	.005" Oversize				
	110-3655-10	2	.010" Oversize				




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
50	120–0491	4	Pump, Oil (Components Not Sold Separately) Spec B–D	64	541–0239	1	Kit, PTO – 7" Pilot Adapter Code 11BH (Includes Parts Marked ~)
	120-0491	1 1	Begin Spec E	65	541-0344	1	/
E 1	120-1275-02	1	Gasket Kit, Oil Pump	05	341-0344	ı	Kit, PTO Bearing Plate Adapter – SAE A – Code 11BE
51 52		1	Spring, Bypass Valve				•
52 53	120-0140	1	Plunger, Bypass Valve	66	541-0374	4	(Includes Parts Marked #) Kit, PTO Bearing Plate
53 54	120–0398 801–0050	1	Screw, Cap – Hex Head	66	341-0374	1	Adapter – SAE B – Code 11BG
34	601 - 0050	ı					•
55	526-0066	1	(3/8–24 x 1") Washer, Flat – Copper	67	98–4240	4	(Includes Parts Marked ^) ^#Label, Blank Kit Number
55	320-0000	1	(3/8" Screw)	68	90-4240	1 ~	Adapter, Hydraulic Pump
56			Ring, Retaining	00	101-0766-01	1	# Code 11BE
30	E10 0004	4			101-0766-01		
	518-0294	4 4	Spec B–D Begin Spec E	69	101-0766-02	ı	Codo Tibi, Tiba
E7	112–0267	4		69			Screw, Cap – Hex Head
57			Kit, Ring – Piston Spec B–D		800-0515	4	(3/8–16 x 1–3/4") # Code 11BE – SAE A
	113–0296		Standard		800–0515	4 5	^ Code 11BF, 11BG – SAE B
	113-0296-05	2	.005" Oversize	70	101–0761	1	~Adapter, Bearing Plate
	113-0296-05	2 2	.010" Oversize	70 71	815–0682	4	~Screw, Hex Recessed
	113-0296-10	2	.020" Oversize	7 1	013-0002	4	(3/8–16 x 1–1/4")
	113-0296-20	2	.030" Oversize	72	160–1368	4	Gasket, Plate
	113-0290-30	2	Begin Spec E	73	160–1345–01	1 1	Plate, Ignition Plunger Cover
	113-0311	2	Standard	73 74	740–1004		Washer, Flat (M6)
	113–0311	2	.005" Oversize	7 4 75	800-0004	2 2	Screw, Hex Head Cap
	113-0311-03	2	.010" Oversize	75	000-0004	2	(1/4–20 x 5/8")
	113-0311-01	2	.020" Oversize	76	309-0559	1	Switch, Cut–Off – High
	113-0311-02	2	.030" Oversize	70	309-0339	'	Temperature
58	114–0203	2	Rod, Connecting (Includes Bolt	77	853-0013	1	Washer, Lock – Ext. Tooth (1/4")
56	114-0203	2	and Bushing)	//	000-0010	'	Washer, Lock – Ext. 100th (1/4)
59	805-0010	4	Bolt, Connecting Rod				
60	003-0010	7	Piston & Ring Set (Includes Pin				
00			and Retaining Rings)	* – F	arts Included in	n the C	ylinder Block.
	110 0005	0					Bearing Plate Adapter Kit SAE A.
	112-0265	2	Standard				Bearing Plate Adapter KIt SAE B.
	112-0265-05	2	.005" Oversize				– 7" Pilot Adapter Kit.
	112-0265-01	2	.010" Oversize				·
	112-0265-02	2	.020" Oversize .030" Oversize				
04	112–0265–03	2					
61	110 0000	0	Pin, Piston				
	112-0069	2	Spec B–D				
60	112–0268	2	Begin Spec E				
62	740–1004	2 4	Washer, Flat (1/4")				
63	803–0071	4	Screw, Socket – Set				
			(3/8–16 x 5/8")				

Camshaft




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	150-0078	1	Ring, Retaining	6			Camshaft
2	150-1519	1	Hub, Governor Cup		105-0594	1	Specs B-G (Includes Center
3	150-1520	1	Cup, Governor				Pin)
4			Ball, Governor		105-0676	1	Spec 11583H Only
	510-0015	5	5 Ball Governor (Hi-Speed)	7	105-0700	1	Gear, Camshaft (Includes Gear,
	510-0015	10	10 Ball Governor - Code				Spacer and Plate)
			13CH (Lo-Speed)	8	105-0541	1	Washer, Thrust – Special
5	515-0001	1	Key, Woodruff - Camshaft Gear	9	150-0075	1	Pin, Center

Crankshaft




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Crankshaft (Includes Keys)	5	515-0001	1	Key, Crankshaft Gear
	104-1340	1	Code 45BB	6	104-1694	1	Spacer – Code 45BE
	104-1698	1	Code 45BE	7			Key, Woodruff – Crankshaft
	104-1314	1	Code 45BF				Stub
	104-1311	1	Code 45BS		515-0263	1	Kit, Flywheel Key
	104-1310	1	Code 45BT		515-0103	1	(1/4 x 1/4 x 2") Code
	104-1500	1	Code 45BU				45BB,45BW
	104-1786	1	Code 45BY		515-0146	1	(#18 x 1/4 x 1-1/8")
	104-0864-01	1	+ Code 45CC		515-0198	1	(3/8 x 3/8 x 2-1/2")
	104-1698	1	Code 45BD				Code 45BW, 45BE
	104-1831	1	+ Code 45EA		515-0230	1	(3/8 x 3/8 x 2") Code 45BD
2	518-0014	1	Ring, Retaining				
3	104–0043	1	Washer, Gear Retaining – Special	+ - [Does Not Incl	ude Keys.	
4	104-1808	1	Gear, Crankshaft				

Blower Wheel With Screen




Oil Base



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Base, Oil (Includes All Plugs and Plug Gasket)	6	505–1462	4	Plug, Hex Head – Special Metric (M22) Code 17DN
	102-1338	1	Spec B (Multidrain)		102-0938	1	Special (Code 17DA)
	102-1384-02	1	Begin Spec C	7	102-0938	1	Gasket, Hex Head Plug
_		!	5 1	/	102-0743	1	,
2	102–1387	1	Gasket, Oil Base	8			Cup, Intake – Oil Pump
3	526-0251	4	Washer, Flat (3/8" Screw)		120-1215	1	Spec B
4			Screw, Cap – Hex Head		120-1230	1	Spec C
	800-0200-01	4	(3/8-16 x 5-3/4") Spec B		120-1272	1	Begin Spec E
	800-0302-01	4	(3/8-16 x 5-1/2") Begin				
			Spec C				
5			Plug				
	505-0110	2	3/8 Pipe				
	505-0266	1	Pipe, Square – Countersunk				

Oil Fill Tube



- Parts included in Inner Oil Fill Tube Kit.

^ - Parts included in Outer Oil Fill Tube Kit.

* - Parts included in Outer Tall Oil Fill Tube Kit.

@- Parts included in Oil Fill Adapter Assembly.

123-1867-51

123-1869-51

123-2105

1

1

1

Painted – Code 17BZ Painted – Code 17BY – Begin


Adapter Assembly, Oil Fill

(Begin Spec H) (Includes Parts

Spec E


Marked @)

Oil Filter



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	122-0814	1	Adapter, Oil Filter	7			Filter, Oil
2	526-0065	2	Washer, Flat - Copper		122-0469	1	With Hex Nut - Code 17CV
			(5/16" Screw)		122-0800	1	Without Hex Nut - Code
3	800-0028-01	2	Screw, Cap - Hex Head				17CD 4.2" Long – Begin
			(5/16-18 x 1") Shakeproof				Spec C Code 17DF
			(Code 17DF)	8	501-0008	1	Line, Flex
4	122-0352-50	1	Drain, Oil Filter – Painted	9	502-0017	1	Connector
5	815-0194	2	Screw, Cap – Hex Head	10	502-0020	1	Elbow, Street
			W/ET (#10-32 x 3/8")	11	505-1426	1	Plug, Countersunk (1/8")
6	122-0771	1	Gasket, Oil Filter Adapter	12	122-0502	1	Gasket, Oil Filter - Code 17CV


Gearcase



Gearcase

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Gearcase Kit (Includes Parts Marked *)	16	191–2104	1	Terminal Kit, Alternator (3 Leads)
	103–0791 103–0799	1 1	All Specs Except 10913 Spec 10913 only	17	503–0301	1	Clamp, Vacuum Port Cap (Spec B only)
2			*Bearing, Governor Shaft	18	149-1321	1	Cap, Vacuum Port (Spec B only)
	510-0105	1	All Specs Except 10913 and	19	166–0785	1	Control, Ignition
			11583H	20	815–0340	2	Screw, Hex Washer Head
_	510-0013	1	Spec 10913 only			_	(10–32x3/8")
3	.=0=0 0.		Shaft And Arm, Governor	21	854-0010	2	Washer, Lock – IT (#10)
	150–1470–01	1	All Specs Except 10913 and 11583H	22	518–0406	1	Clip, Retaining – Control Rod To Governor Shaft
	150-1422-01	1	Spec 10913 only	23	166–0786	1	Insulator, Ignition Module
4	150–1187	1	*Yoke, Governor Shaft (All Specs Except 11583H)	24	541–0259	1	Kit, 35 Amp Alternator (Includes Parts Marked +) Code 31BC
5	815-0046	2	*Screw, Machine - Pan Head	25	E-0327	1	+Sheet, Instruction (Not Shown)
			(8-32x3/8") (All Specs Except	26	98-4240	1	+Label, Blank Kit Number
			11583H)	27	191–1276	1	+Stator, Alternator
6	516–0130	1	*Pin, Dowel – Governor Cup Stop		191–1276	1	35 Ampere (Code 31BC)
			(All Specs Except 11583H)		191–1456	1	20 Ampere (Code 31AZ)
7	509–0008	1	*Seal, Oil – Governor Shaft (All Specs Except 11583H)	28	191–1847	1	+Regulator, 35 Amp Voltage (Shown on Blower Housing
8	510-0014	1	*Ball, Bearing – Governor Shaft				Page)
			(All Specs Except 11583H)	29	815–0659	3	+Screw, Machine – Hex Head
9	509-0040	1	*Seal, Oil – Crankshaft, Front				Self-Lock (#10-32x1")
10	103-0810	1	Gasket, Gearcase Mounting	30	821–0010	1	+Screw, Lock Head
11	800-0032-01	4	Screw, Cap – Hex Head	0.4	050 0010		(1/4–20 x1/2") (Not Shown)
10	526-0065	E	(5/16–18x1–3/4")	31 32	853–0013 517–0293	1	+Washer, ET Lock (Not Shown)
12		5	Washer, Flat – Copper (5/16" Screw)	32	517-0293	1	Plug, Expansion (Spec 11583H Only)
13	149–1299	1	*Tube, Vacuum Port (1.5" Long) (Spec B only)				
14	520-0933	1	Stud, Gear Cover		Parts included		
15	862–0015	1	Nut, Hex (5/16–18) Stator (Includes Terminals)	+ – F	Parts included	in 35 An	np Alternator Kit.


¹⁷



Air Cleaner


REF NO.	PART NO.	QTY USE		REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Kit, Air Cleaner - Code 19AS	13	526-0234	3	Washer, Flat (#10 Screw)
			(Standard Capacity)	14	145-0522	1	Plate, Air Deflector
į	541–0457–01	1	Begin Spec B (Includes Parts	15			Tube, Air Intake
			Marked *)		503-1882-01	1	3.5" Long
į	541–0457–02	1	Begin Spec C (Includes Parts		503-1882-02	1	4.12" Long
2			Marked #) Kit, Air Cleaner – Code 19AU	16	503–1882–03 140–2191–50	1 1	5.12" Long Support, Air Cleaner
2			(High Capacity)	17	508-0021	1	Grommet, Rubber (3/4" Hole)
!	541-0458-01	1	Begin Spec B (Includes Parts	18	541–0459	1	Cover, Element
`	011 0100 01	•	Marked ~)	19	870–0365	1	Nut, Hex (1/4–20)
ļ	541-0458-02	1	Begin Spec C (Includes Parts	20	301–0458	1	Spacer, Air Cleaner Stud
			Marked ^)	21	520-0948	1	Stud – Code 19AU
3 I	E-347a	1	~*Sheet, Instruction (Not Shown)	22			Hose, Breather
4 I	E-348b	1	^#Sheet, Instruction (Not Shown)		503-1606-01	1	Old Style
5 9	98–4240	1 ~	^*#Label, Blank Kit Number		503-1606-02		^# Tool–Less
6			Cover, Air Cleaner	23	503-1133		^#Clamp, Hose
	140-2005-50	1	*# Code 19AS (Standard)	24	312-0256	1	Capacitor (Placed Horizontal)
	140-1913-50	1	~^ Code 19AU,19CL (XSL)	25	815–0389	1	Screw, Hex Head (1/4-20 x 3/8")
	140–2005–02	1	Code 19BB – Begin Spec C	26	440.0704		Cover, Inner – Tool–Less
7			(Chrome)		140-2794	1 1 ~^	Spec A–F
7	140–1496–01	1	Wrapper, Air Cleaner Element *# Code 19AS	27	140–2942	1 ~'`	*# Begin Spec G Spacer, Air Cleaner Stud
	140-1496-01	1	Code 19AS Code 19AU,19CL	21	140-2536-01	1	*# Extended Service Life &
8	140-1912-01	'	Element, Air Cleaner		140-2550-01	'	Standard Capacity 1" Long
-	140-2628-01	1	*# Code 19AS – Standard		140-2536-02	1 -	~^ High Capacity – 2.75" Long
			Capacity – Extended	28	140–2761		*#Knob, Tool–Less
			Service	29	815-0463		*#Screw, Slotted – Hex Washer
	140-2628-02	1	~^ Code 19AU,19CL – High				Head (10-32 x 3/8")
			Capacity	30	865-0029	1	Nut, Wing
9 8	870–0399	1	Nut, Hex Washer Head	31	865-0020	1	Nut, Wing (1/4-20)
			Flanged (5/16–18) Code 19AV	32	145–0614	1 -	~^Plate, Air Deflector – High
10			Housing, Air Cleaner				Capacity
	140-2493-51	1	* Code 19AS – Painted	33	140–2786	1 ~^	*#Spacer, 1/2"LG - Standard and
	140-2539-51	1	~ Code 19AU – Painted				High Capacity
	140–2493–53	1	# Begin Spec C – Use with Standard Filter				
	140–2539–53	1	Begin Spec C – Use with	* _ [Parte included i	n 5/1_	0457–01 Air Cleaner Kit.
	140-2559-55	'	High Capacity Filter				0457–01 All Cleaner Kit. 0457–02 Air Cleaner Kit.
11 8	815–0575	2	Screw, Tapping – Hex Washer				0458–01 Air Cleaner Kit.
、	2.0 00/0	_	Head (1/4–20 x 3/8")				0458–02 Air Cleaner Kit.
12 8	815–0470	3	Screw, Hex Head – Machine	•			
			(#10–32 x 1–1/2")				

Remote Air Cleaner Adapter




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541-0320	1	Kit, Remote Adapter Air Cleaner	10	98-4240	1	*Label, Blank Kit Number
			(Includes Parts Marked *)	11	123-1871	1	Filter, Breather Tube
			Code 19AV	12	123-1539	1	Tube, Breather - Crankcase
2	509-0145	1	*Seal, O-Ring	13	312-0256	1	Capacitor
3	850-0030	3	*Washer, Lock - Spring (#10)	14	815-0178	1	Screw, Hex Washer Head
4	503-1396	1	*Hose, Breather				Thread Form (10-32 x 5/8")
5	853–0013	1	*Washer, Lock – External Tooth (1/4")	15	503-0398	1	Clamp, Breather Tube (1–5/8" Diameter)
6	140-1714	1	*Adapter, Air Intake	16	140-1428	1	Elbow, Air Inlet
7	813–0106	3	*Screw, Machine – Round Head (#10–32 x 1–1/8")	17	503–1141	1	Clamp, Hose (2–3/8" Diameter)
8	517-0252-01	1	*Plug, Hole				
9	503-0171	2	*Clamp, Hose (11/16" Dia.)	*- P	arts included	in Air Clea	aner Kit.

Remote Air Cleaner




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541–0147	1	Kit, Air Cleaner Remote Elbow (Include Parts Marked *)	8	140–0723	1	Precleaner, Air Cleaner (Plastic)
			Code 19CJ	9	140-2173	1	Tube, Air Induction (Steel)
2	140-1428	1	*Elbow, Air Inlet	10	800-0004	4	Screw, Hex Head Cap
3	503-1141	4	*Clamp, Hose				(1/4-20 x 5/8")
			(2-3/8 x 1/2" Band)	11	870-0065	4	Nut, Self-Lock (1/4-20)
4	98-4240	1	*Label, Blank Kit Number	12	526-0018	8	Washer, Flat (1/4" Screw)
5	140-0721	1	Cleaner, Air (Includes Element)				
6	140-2860	1	Element, Air Cleaner				
7	140-0722	2	Band, Air Cleaner	*– P	arts included	in Remote	Elbow Kit.

Fuel System Gasoline




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Carburetor, Completd (Includes	6	740-1006	2	Washer, Flat (M8)
			Mounting Gasket, Elbow and	7	154-2219	2	Gasket, Intake Manifold
			O–Ring) (See Separate Page for Components)	8	518–0004	1	Clip, Retaining – Control Rod To Carburetor
	146-0497	1	Spec B-F	9	150-2553	1	Rod, Governor Control
	146-0662	1	Begin Spec G (Emissions	10			Hose, Fuel
			Carbuetor) (Includes		503-1199	1	24" Long
			Gasket Only)		503-1418	1	15" Long
2	154–0733	1	Gasket, Carburetor Mounting Manifold, Intake	11	503-1606-01	1	Hose, Rubber Breather (3.25" Long)
3	154–2873	1	Code 15BD	12	502-1038	1	Fitting, Barbed – Code 19AU
	154–2075	1	Code 15CU	13	503-0731	2	Clamp, Hose – (1/2" Diameter)
4	800-0035	2	Screw, Cap – Hex Head	14	303-0731	_	Washer, Flat
7	000 0000	_	(5/16–18 x 2–1/2")	17	526-0251	4	Spec B (3/8" Screw)
5			Screw, Cap – Hex Head		526-0251	2	Begin Spec C (3/8" Screw)
			(3/8-16 x 3")		526-0122	2	Begin Spec C (5/16" Screw)
	800-0058	4	Spec B (3/8-16 x 3")	15	503-1133	1	Clamp, Hose - Breather
	800-0058	2	Begin Spec C (3/8-16 x 3")	16	150-2409	1	Spring, Rod – Governor
	800–0036	2	Begin Spec C (5/16–18 x 2–3/4")				

Carburetor Components Nikki Spec B




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	146-0431	1	Carburetor, Complete (Includes	5	146-0426	1	Jet, Idle
			Mounting Gasket)	6	146–0501	1	Jet, Power – Fixed – Standard
1	146–0437	1	Kit, Float (Includes Float, Pin and Valve)	7	146–0467	1	Solenoid, Fuel Cut-Off (Includes Gasket)
2	146-0500	1	Kit, Repair (Includes Screw And	8	146-0505	1	Kit, Throttle Shaft
			Plug Package, Gasket	9	146-0435	1	Kit, Choke Lever
			Package, Float Valve, Idle	10	146-0433	1	Kit, Choke Shaft
			Adjust Needle and Spring, Mounting Gaskets, Idle Limit Cap)	11	145–0438	1	Gasket, Carburetor Mounting
3	154-0733	1	Gasket, Carburetor Mounting				
4	146–0424	1	Jet, Power – Fixed – Optional (High Altitude Application) (Package) (Includes Float Valve, Idle Jet, Power Jet, Idle Needle–Adjust, and Power Jet Gasket)				

Carburetor Components Nikki Spec C



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Carburetor, Complete (Includes	5	146-0426	1	Jet, Idle
			Mounting Gasket)	6	146-0501	1	Jet, Power – Fixed – Standard
	146-0497	1	Begin Spec C	7	146-0502	1	Kit, Fuel Cut-Off Solenoid
1	146–0437	1	Kit, Float (Includes Float, Pin and Valve)				(Includes Cut-Off Solenoid, Crimp Terminal, and Gasket)
2	146-0500	1	Kit, Repair (Includes Screw	8	146-0499	1	Gasket, Mounting
			And Plug Package, Gasket	9	146-0433	1	Kit, Choke Shaft
			Package, Float Valve, Idle	10	146-0435	1	Kit, Choke Lever
			Adjust Needle and Spring, Mounting Gaskets, Idle Limit Cap)	11	146–0505	1	Kit, Throttle Shaft
3	154-0733	1	Gasket, Carburetor Mounting				
4	146–0424	1	Jet, Power – Fixed – Optional (High Altitude Application) (Package) (Includes Float Valve, Idle Jet, Power Jet, Idle Needle–Adjust, and Power Jet Gasket)				


Carburetor Components Begin Spec G



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	146–0662	1	Carburetor, Emissions (Includes Parts Marked *)	7	146–0649	1	*Repair Package, Accelerator Pump
2	146-0338	4	*Screw, Valve Set	8	146-0502	1	Repair Kit, Solenoid Valve
3	146-0423	1	*Valve, Float	9	146-0657	1	*Repair Kit, Float and Gasket
4	146-0331	1	*Spring, Adjustment Screw	10	146-0658	1	*Repair Kit, Accelerator Pump
5	146-0339	1	*Plug, Expansion	11	146-0695	1	*Jet, Main Fuel High Altitude
6	146–0650	1	*Repair Package, Float and Gasket	*_	Parts included	d in Emiss	sions Carburetor.


^{*-} Parts included in Emissions Carburetor.

Fuel System LP Carburetor




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	146-0562	1	Carburetor, LP	13			Screw, Cap – Hex Head
2	503-1798-01	1	Hose, Fuel (3/8" ID x 27" Long)		800-0058	4	Spec B (3/8-16 x 3")
3	503-1133	2	Clamp, Hose		800-0058	2	Begin Spec C (3/8-16 x 3")
4	332-1356	1	Clamp, Loop		800-0036	2	Begin Spec C
5	141-0281	1	Gasket, Carburetor Mounting				(5/16-18 x 2-3/4")
6	140-2722-01	2	Spacer, Air Cleaner	14	154-2873	1	Manifold, Intake
7	503-1882-03	1	Hose, Air Inlet	15	800-0035	2	Screw, Cap – Hex Head
8	503-1606-03	1	Hose, Breather				(5/16–18 x 2–1/2")
9	821-0013	2	Screw, Cap – Hex head	16	740-1006	2	Washer, Flat
			(1/4-20 x 1)	17	332-1794	1	Tie, Cable (Self-Locking)
10	526-0018	2	Washer, Flat (1/4" Screw)				
11	502-1146	1	Elbow, Brass – 45° (Included				
			with Carburetor)				
12			Washer, Flat (M8)				
	526-0251	4	Spec B (3/8" Screw)				
	526-0251	2	Begin Spec C (3/8" Screw)				
	526-0122	2	Begin Spec C (5/16" Screw)				


Fuel System Dual Fuel



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-0733	1	Gasket, Carburetor Mounting	7	503-1133	2	Clamp, Hose
2	140-2722-02	2	Spacer, Air Cleaner	8	503-1882-04	1	Hose, Air Inlet
3	800-0011	2	Screw, Hex Washer Head	9	148-0981-02	1	Mixer, LPG
			(1/4-20 x 2")	10	148-0984-02	1	Jet, Idle
4	526-0018	2	Washer, Flat (1/4" Screw)	11	149-2385	1	Tube, Idle Feed
5	503-1606-05	1	Tube, Breather	12	332-1356	2	Clamp, Loop
6	503-1798-01	1	Hose, Fuel – 27" Long				




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Housing, Blower	20	815-0436	2	^Screw, Cap - Hex Washer Head
	134–4850	1	Without Oil Cooler (Spec B)				(1/4-20 x 1/2") - Code 13BJ
	134-5001-50	1	Spec B–D	21	500 0004	•	Washer, Flat (1/4" Screw)
	134–4986–02	1	Spec E–G (Painted)		526-0021	2 2	^ 3/4" OD – Code 13BJ
	134-4986-02	1	Spec H With Control Panel	22	526–0018 150–1269	1	5/8" OD – Code 13CD,13BJ
	134-4900-02	'	Code 39AG, 35CK,	23	150-1269	1	^Bushing, Governor Control Arm ~Stud, Adjusting – Code 13CG
			and 35DB (With Harness)	24	541–0191	1	Kit, Front Pull Governor
	134-5127-02	1	Without Control Panel		011 0101	•	(Code 13BK) (Includes Parts
2		•	Housing, Cylinder Air – LH				Marked #)
	134-4668-50	1	Without Weld Nuts	25	815-0391	1	#Screw, Tapping – Hex Head
	134-4668-51	1	With Weld Nuts				(#10–32 x 1/2")
3			Housing, Cylinder Air – RH	26	153-0514	1	#Clamp, Throttle Cable
	134-4846-50	1	Without Weld Nuts	27	150-1726-01	1	#Bracket, Governor Control
	134–4846–51	1	With Weld Nuts				Mounting – Zinc Plated
4	815–0290	2	Screw, Tapping – Hex Washer	28	526-0021	1	Washer, Flat (1/4" Screw)
_			Head (1/4–20 x 5/8")	29	850-0040	1	Washer, Lock – Spring (1/4")
5	526-0021	2	Washer, Flat (1/4" Screw)	30	800–0007	1	#Screw, Cap – Hex Head
6	821–0016	2	Screw, Cap – Hex Washer	21	815–0439	3	(1/4–20 x 1") #Screw, Hex Washer Head
7	815-0337	3	Head (5/16–18 x 3/4") Screw, Tapping – Hex Washer	31	015-0459	3	Tapping (8–15 x 1/2")
,	015-0557	3	Head (1/4–20 x 3/4")	32	150–1727	1	#Bushing, Governor Control
8	150-2264	1	Bracket, Governor Adjust	33	152–0155	1	#Swivel, Throttle Lever
Ü	100 2201	•	(Plated) Code 13CG	34	516-0059	1	#Pin, Cotter
9	526-0018	4	Washer, Flat (1/4" Screw)	35	815–0693	1	#Screw, Machine – Hex Head
10	541-0424	1	Kit, Fix Speed Governor				(#8–32 x .318")
			(Code 13CG) (Includes Parts	36	150-1366	1	#Link, Governor Control
			Marked ~)	37	150-1754-01	1	#Adapter, Governor Arm
11	541-0213	1	Kit, Side Pull Governor	38	815–0194	2	#Screw, Hex Head W/ET
			(Code 13BJ) (Includes Parts				(#10–32 x 1/2")
40			Marked ^)	39	150–1755	1	#Spring, Governor
12	150 1014	4	Spring, Governor	40	E17 0061	4	Plug, Black Nylon
	150–1214 150–1740	1	~^ 5 Ball Governor 10 Ball Governor–Code		517–0261 517–0136	1 1	Code 23DE (57mm) Code 13BJ,13CD,15BB
	130-1740	'	13CH		317-0130	'	(23.4mm)
13	153-0514	1	^Clamp, Cable – Code 13BJ	41	821-0008	4	Screw, Cap – Hex Washer Head
14	150-1725-01	1	^Bracket, Governor Mounting		0 0000	•	(1/4–20 x 5/16")
			Code 13BJ	42	149-2242	1	Bracket, Fuel Line - Begin Spec
15	815-0359	1	^Screw, Tapping – Hex Head				С
			(#10-32 x 1/2") - Code 13BJ	43			Regulator, Voltage
16			Arm Assy, Governor Control				Spec A-D
	150–1761	1	^ Includes Parts Marked @		191–2106	1	20 Ampere – Code 31AZ
	150 0504 04	4	(Code 13CB)		101 0007	4	Begin Spec E
	150–2504–01	1	Includes Parts Marked < (Code		191–2227	1	20 Ampere – Code 31AZ 35 Ampere – Code 31BC
17			13BN) Screw, Hex Head	44	191–1847 403–4202–02	1 2	Bracket, Lifting (Plated)
17	815-0510	1	@ Tapping (#6–32 x 5/8")	45	821–0010	5	~Screw, Lock Head
	010 0010	•	Code 13BJ	10	021 0010	Ü	(1/4–20 x1/2")
	815-0563	1	< Thread Form	46	518-0515	1	Clip, Wire - Code 13BJ,13BK
			(#6-32 x 1-3/8")				13CD (Spec B thru G only)
			Side Pull Governor –	47	526-0006	1	#Washer, Flat (#12 Screw)
			Variable Speed				Code 13BK
18	150–1398	1 <	@ Spring, Idle Setting –	48	815–0474	1	Screw, Hex Washer Head
			Code 13BJ				(1/4–14 x 1/2") – Code 13BJ
19			Arm, Governor Control (With-				13BK,13CD – Code 13CG
	150 1570	4	out Swivel)				(Spec B thru G only)
	150–1576 150–1576–02	1 1	@ Code 13BJ < Code 13DD				
	130-1370-02	1	COUG TODD				



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
49	870–0131	1	~Nut, Hex – Governor Adjusting (W/ET 10–32) – Code 13CG	64	541–0369	1	Kit, Stationary Grill with PTO Access (Code 23ED) (Includes
50	150-0621	1	~Nut, Governor – Acorn,				Parts Marked +)
51	815–0261	1	Screw, Hex Washer Head (1/4–20 x 1/2")	65	815–0575	4	Screw Hex Washer Head
52	150–2264	1	~Bracket, Governor Adjust – Zinc Plated – Code 13CG		815–0721	4	(1/4–20 x 3/8") +*Pan Head – Taptite (Special)
53	150-0639	1	Joint, Ball – Code 13CG		010 0721	•	(10–32 x 1)
54	150–2364	1	Rod, Governor – Code 13CG				Code 23DN, 13CD
55	518-0406	1	Clip, Retaining – Control Rod Code 13CG	66	134–4689	1	Guard, Stationary No Center Hole
56	815–0181	1	Screw, Thread Cutting – Hex Head W/ET (#10–32 x 1/2")		134–4689–01 134–4689–02	1 1	*Center Hole – 1" Dia. +Center Hole – 3.88" Dia.
57	150–2388	2	Lever, Governor – Code 31AZ Begin Spec C	67 68	99–2393 98–4240	1 1 *+#	*Nameplate, Logo *ALabel, Blank Kit Number
58	150–2553	1	Rod, Governor Control (Zinc Plated)				
59	518-0004	1	Clip, Retaining – Control Rod to Carburetor				t Pull Governor Kit. nary Grill Kit without PTO Access.
60	508-0021	1	Grommet, Rubber – Code 13BJ				onary Grill Kit with PTO Access.
61	508–0331	1	Grommet, Rubber – 20, 35 Amp Voltage Regulator Harness – Begin Spec E	^ – @ –	Parts included Parts included	in Side in 150–	Pull Governor Kit. 1761 Governor Control Arm Assy. 2504–01 Gov. Control Arm Assy.
62			Plug, Hole – Code 19AV				Speed Governor Kit.
	517-0252	1	Plated				•
	517-0174	1	Tapered				
63	541–0296	1	Kit, Stationary Grill Without PTO Access (Code 23DN) (Includes Parts Marked *)				


Remote Fuel Pump (Electric)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	149–1828	1	Kit, 12 Volt Electric Fuel Pump (Includes Parts Marked *)
2	332-0529	1	*Tèrminal, Crimp
3	332–1993	1	*Terminal


^{*-} Parts included in 12 Volt Electric Fuel Pump Kit.

Two Speed Governor (Code 13BF)




REF NO.	PART NO.	QTY USE	PART D DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541-0418	1	Kit, 2 Speed, 12 Volt Solenoid	15	307–2758	1	*Solenoid, Governor
			Governor (Code 13BF)	16	508-0021	1	*Grommet, Fuel Line Bracket
			(Includes Parts Marked *)	17	526-0021	1	*Washer, Flat (1/4" Screw)
2	150-2545	1	Bracket Assembly, Governor	18	800-0007	1	*Screw, Cap – Hex Head
_			(Includes Parts Marked #)			_	(Special)
3	517–0177	1	#Plug, Cap	19	815–0439	2	*Screw, Cap – Hex Washer Head
4	800–4072	1	#*Screw, Machine – Hex Head			_	(#8–15 x 1/2")
			(M4)	20	821–0010	3	*Screw, Lock Head
5	153–0632	1	#*Swivel, Choke Lever				(1/4–20 x 1/2")
6	526-0006	1	#*Washer, Flat (#12 Screw)	21	115-0025	1	*Nut, Hex (1/4–28)
7	516-0059	1	#*Pin, Cotter	22	870-0212	2	*Nut, Lock (1/4–20)
8	150-2498	1	#*Bracket, Governor	23	E-350	1	*Sheet, Instruction (Not Shown)
9	150-1740	1	*Spring, Governor (Low Speed)				
10	149-2242	1	*Bracket, Fuel Line				
11	150-1727	1	*Bushing, Governor Control	* —	Parts included	l in 2 Spe	ed, 12 Volt Solenoid Governor Kit.
12	150-2499	1	*Bracket, Solenoid Mounting				rnor Bracket Assemly.
13	153-0678	1	*Cable Assy (Includes Screw)				ŕ
14	815-0800	1	*Screw, Hex Head - Grade 5				
			(1/4-28 x 1") (Included in				
			Cable Assy)				

Choke Control (Front Pull)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541–0190	1	Kit, Front Pull Choke (Includes Parts Marked *) Code 15BJ	9	815–0693	1	*Screw, Machine – Hex Head (#8–32 x.3/8")
2	526-0140	2	*Washer, Flat (#10 Screw)	10	516-0059	1	*Pin, Cotter
3	153-0523	1	*Lever, Choke	11	815-0359	1	*Screw, Tapping - Slotted
4	153-0500	1	*Link, Choke				Hex Washer Head
5	153-0524	1	*Bracket, Choke Cable				(#10-32 x 7/8")
6	821–0004	1	*Screw, Cap – Hex Washer Head (#10–32 x 5/16")	12	153–0514	1	*Clip, Choke Cable
7	815–0820	1	*Screw, Shoulder (#10–32 x 3/8")	*– P	arts included	in Front F	Pull Choke Kit
8	152-0155	1	*Swivel, Choke Lever				

Choke Control (Rear Pull)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-0004	2	Screw, Cap - Hex Washer	3	153-0514	1	Clip, Choke Cable
			Head (10-32x5/16")	4	815-0359	1	Screw, Tapping – Slotted Hex
2	153-0686-02	1	Bracket, Choke Cable				Washer Head (#10-32 x 7/8")

Remote Choke Spec C




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541–0412	1	Kit, Remote Choke (Includes Parts Marked +) Code 15CK	12	153–0642	1	+Bracket Assy, Choke (Includes Parts Marked *)
2	153-0500	1	+Link, Choke	13	526-0008	2	*Washer, Flat (#10 Screw)
3	821-0004	2	+Screw, Lk H (#10-32 x 3/8")	14	150-2480	1	*Bracket, Choke
4	518-0006	1	+Clip, Lock	15	150-2531	1	*Lever, Choke
5	150-2478	1	+Rod, Choke	16	815-0480	1	*Screw, Pan Head
6	870-0053	1	+Nut, Hex Mach (10-32)				Shoulder (#10-32)
7	150-2481	1	+Joint, Ball	17	870-0298	1	*Nut, Lock (#10-32)
8	870-0212	2	+Nut, Self Lk (1/4-20)				
9	815-0290	4	+Screw, HWH THD Form				
			(1/4-20 x 5/8)	+-	Parts included	d in Remo	te Choke Kit.
10	307-2751	1	+Bracket, Solenoid	* —	Parts Include	d in Chok	e Bracket Assy.
11	307-2750	1	+Solenoid, 12 Volt				-

LPG Conversion Kit




LPG Converter Kit



REF NO.	PART NO.	QT USE		REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541–0442	1	Kit, LPG Converter #1 Cylinder Mounting (Includes Parts Marked *)	7	815–0293	1 *@	Screw, Hex Washer Head Thread Forming (1/4–20 x 3/4")
	541–0443	1	#2 Cylinder Mounting (Includes Parts Marked @)	8			Screw, Hex Head Cap (1/4–20 x 5/8")
2	148-1025	1	*@ Converter, LPG		821-0018	4 *	#1 L.H. – Cylinder
3	307-2754	1	*@Shut Off, Fuel Solenoid		821-0018	3 @	#2 R.H. – Cylinder
4			Bracket, Upper	9	332-1794	2 *@	Tie, Cable
	148-0973	1	* L.H. Mount (#1 Cyl)	10	98-4240	1 *@	Label, Blank Kit Number
	148-0975	1	@ R.H. Mount (#2 Cyl)	11	E-356	1 *@	Sheet, Instruction (Not Shown)
5			Bracket, Lower				
	148-0974	1	* L.H. Mount (#1 Cyl)				
	148-0976	1	@ R.H. Mount (#2 Cyl)	* —	Parts include	d in #1 Cyli	nder Mounting Kit.
6	502–1145	1	*@ Elbow, 90° Brass (1/2"NPT – 3/8 Barb)	@ –	Parts include	d in #2 Cyli	nder Mounting Kit.


Starter



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Starter – Solenoid Shift (See Separate Page for	4	541–0411	1	Kit, Starter Cap (Includes Parts Marked *)
			Components)	5	E-0342	1	*Sheet, Instruction (Not Shown)
	191-1949-04	1	Code 33AT	6	191-1947	1	*Cap, Starter Solenoid
	191-1949-07	1	Code 33AW	7	750-1006	1	*Nut, Hex
2	526-0122	2	Washer, Flat (5/16" Screw)				
3	800–0595	2	Screw, Cap Hex Head (5/16"–18 x 3–1/2")	* _	Parts include	ed in Star	ter Can Kit


³⁹

Starter Components




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	191–1954	1	Kit, Hardware – Starter (Includes (2) Solenoid Mtg Screws, 2 Thru Bolts, Armature Shims, Pinion Stop	5	191–1951	1	Kit, Brush – Starter (Includes (2) Negative and (2) Positive Brushes and Brush Holder)
			Collar, Retaining Ring and Solenoid Terminal Nuts)	6	191–1766	1	Kit, Shift Lever – Starter (Includes Lever, Wear Plate,
2	191–1956	1	Kit, Solenoid – Starter (Includes Solenoid and Spring Plunger)	7	191–1953	1	Rubber Plug and Grease) Kit, Clutch – Starter (Includes Pinion Gear, Clutch Assy & #8)
3	191–1931	1	Kit, Bushing – Starter (Includes Rear Cap with	8	191–1955	1	Kit, Dust Seal (Includes ID, OD Pinion Seals)
			Bushing and Front Bushing)	9	191-1947	1	Cap, Starter Solenoid
4	191–1950	1	Kit, Mounting Bracket (Includes Front Bracket, Front Bushing, Dust Seal, Thrust Washer, Cap Plug and OD Pinion Seal)	10	750–1006	1	Nut, Hex – Metric (M8)

Control Panel




Clutch




REF NO.	PART NO.	QTY USE	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1 2	520–0739 800–0075	3	#Stud (3/8-24 x 3/8-16 x 3") #Screw, Cap - Hex Head	10 11	515–0041 520–0738	1	#Key, Drive - Special #Stud (3/8-24 x 3/8-16 x 4")
۷	000-0075	0	(7/16–14 x 2")	12	190–0597	1	Kit, PTO Electric Clutch Adapter
3	850-0055	3	#Washer, Lock - Spring (7/16")				Code 45BA
4	104-0091	1	#Nut, Hex - Hardened	13	190-0289	1	Kit, Clutch (Includes Parts
5	850-0050	1	#Washer, Lock - Spring (3/8")				Marked #)
6	190-0288	1	#*Clutch				
7	104-0091	4	#Nut, Hex - Hardened				
8	850-0050	3	#Washer, Lock - Spring (3/8")		•		ck nameplate and contact
9	190–0171	1	#Adapter, Clutch		nearest Rock Parts Included		

Fuel Tank (Side Mounted)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	RI No	EF O.	PART NO.	QTY USED	PART DESCRIPTION
1	159-0981	1	*Tank, Fuel (Less Cap)			505-0041	1	*Elbow, 90° - Carburetor Inlet
			* (3.75 Gallon)	1	0	813–0108	2	*Screw, Machine – Round Head
2	159–0596	2	*Strap, Fuel Tank					(#10-32 x 1-1/2")
3	159-0595	2	*Bracket, Fuel Tank	1	11	870-0053	2	*Nut, Hex (#10-32)
4	134-0599	1	*Clip, Line - Fuel	1	2	159-0597	1	Kit, Fuel Tank (Side Mounting)
5	501-0008	1	*Line, Fuel					(Includes Parts Marked *)
6	159-0020	1	*Cap, Fuel Tank					
7	504-0013	1	*Valve, Shut-off	*-	- P	arts included	in Side N	Nounting Fuel Tank Kit.
8	505-0057	1	*Plug, Drain – Tank					-

Low Oil Pressure Cut-Off Switch



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	541-0235	1	Switch, Low Oil Pressure Kit,1 Terminal Code 35AU		541-0436-02		Kit, 3 Terminal – Code 35BV – Dual Circuit to Open/Close at 5 PSI
			Normally Closed 2.01" Long		309-0583	1	Screw On Connector
	309-0546	1	Screw On Connector		309-0646-04	1	Slip On Connector
	309–0615	1	Slip On Connector Code 35AH Normally Open – 2.06" Long				3 Terminal – Code 35BV – Dual Circuit to Open/Close at 10 PSI
	309-0641-17	1	Screw On Connector		309-0609	1	Screw On Connector
	309-0646-01	1	Slip On Connector		309-0646-05	1	Slip On Connector
	541-0236	1	Kit, 2 Terminal Code 35AV Normally Open – 1.87" Long	2	502–0053	1	Elbow, 45° Street – Spec A–D Code 35AH,35AV
	309-0641-18	1	Screw On Connector				
	309-0646-02	1	Slip On Connector				
	541–0319		Kit, 2 Terminal Code 35BW One Terminal Normally Open One Terminal Normally Closed				


Wiring Harness



Wiring Harness


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QT\ USE	
			Harness, Wiring – Engine Units Without Pressure Switch (4 Leads) Code		338–3616	1	Unit With Push On Terminals To The LOP Switch (Includes Parts Marked ^)
	338–2104–01	1	35CH,35CJ, 35CK (Prior to Spec E) Screw On Connector	1	541–0175	1	Kit, 4 Pin Harness Connector Code 35BB (Includes Parts Marked *)
	338–3178–01	1	Slip On Connector Units With Pressure Switch (6 Leads) Code 35BC,35BZ	2	541–0195	1	Kit, 6 Pin Harness Connector Code 35BC (Includes Parts Marked +)
	338–2104–02 338–3178–02	1	(Prior to Spec E) Screw On Connector Slip On Connector	3	541-0437-02	1	Kit, 4 Wire, 6 Pin Wiring Harness (Begin Spec E) (Includes Parts Marked #)
			6 Pin Connector – 3 Terminal LOP Switch – Code 35CC (Prior to Spec E)	4 5 6	E-364 98-4240 E-0313	1 1 1	#Sheet, Instruction (Not Shown) #Label, Blank Kit Number +*Sheet, Instruction (Not Shown)
	338–2804–02 338–3185–02	1	Screw On Connector Slip On Connector 6 Pin Connector – 2 Terminal	7 8 9	323–1382 332–0819 323–1386	1 2 1	*Housing, Tab (4–Way) Housing, Connector – Push On Housing, Receptacle – 6 Way
			LOP Switch – Normally Open Code 35CC (Prior to Spec E)	10 11	332–1567 518–0515	2	#+*Tie, Cable #Clamp, Cable (1/2" Dia.) (Spec B thru G only)
	338–2804–01 338–3185–01	1	Screw On Connector Slip On Connector 6 Pin/6 Wire Code 35BC,	12 13	323–0916 332–2301	1	#+Housing, Connector – Tab 6 Pin Terminal #+* Used with 20 Amp Charging
	338–2851–02	1	35BZ- to Relocate Voltage Regulator Begin Spec E Screw On Connector		332–1503	2	System – 18 to 14 Gauge Wire #+* Used with 35 Amp Charging
	338–3187–02	1	Slip On Connector 5 Pin Connector – 2 Terminal LOP Switch (Normally	14	332–2890 815–0474	5 1	System Code 35CC Screw, Hex Washer Head
	338–2805	1	Open) Code 35CK (Prior to Spec E) Screw On Connector	15	332–0806	2	(1/4–14 x 1/2") (Spec B thru G only) ^Terminal, Ring (#8)
	338–3186	1	Slip On Connector 6 Pin Connector – 2 Terminal LOP Switch Normally Open Begin Spec E – Code 35CC	16 17 18 19	332–1303 332–2715 357–0030 332–3165	5 2 1 1	Terminal, Spade (#10) Terminal, Receptacle Rectifier, Silicon – Code 35CC Receptacle, Lock
	338–2852–01 338–3188–01	1	Screw On Connector Slip On Connector Pin Connector – 3 Terminal	20 21 22	332–3103 332–3143 332–1048 332–2973	1 1 3	Receptacle, Lock Receptacle, Lock Terminal, Ring (.38) Terminal, Spade (#8)
	338–2852–02	1	LOP Switch – Begin Spec E Code 35CC Screw On Connector	23 24 25	332–1993 323–0987 332–2073	2 1 2	Terminal, Receptacle Body, Connector – Code 35CK Terminal
	338–3188–02	1	Slip On Connector 6 Pin Connector – 4 Wire to Relocate Voltage Regulator Begin Spec E – Code 35CH, 35CJ, 35CK	26 27 28 29 30	323–1451 332–2944 323–1216 332–2870–01 321–0291	1 1 2 6 1	^Housing, Receptacle (4 RCPT) ^Terminal, Ring (.312) Insulation ^Body, Connector ^Terminal, Receptacle (#.250) ^Fuse, 30 AMP
	338–2851–01 338–3187–01 338–3187–02		Screw On Connector # Slip On Connector Use On Spec 11583H and Spec 11590H 5 Pin Connector – 2 Terminal	31 32 33 34 35	323–1424 332–2922 357–0030 323–1576 323–1607	1 2 1 4 4	^Cap, Connector ^Terminal ^Rectifier, Silicon ^Seal, Cable (Gray) ^Contact, Socket
	338–2857 338–3189 338–3376	1 1 1	Begin Spec E With LOPKO Code 35CK Screw On Connector Slip On Connector Without LOPKO Code 35DB	+ - F # - F	Parts included ir Parts Included ir	า 6 Pi า 4 W	in Harness Connector Kit. n Harness Connector Kit. Ire, 6 Pin Wiring Harness Kit. -3616 Engine Wiring Harness.

Wiring Harness Lopko




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Harness, Wiring – Lopko Code 35BY – 4 Pin, 3 Wire –	2	332–2890	3	Terminal, Receptacle Terminal, Spade (#10)
			Ext Spec C		332-2973	1	Code 35BY
	338-2454	1	Screw On Connector		332-1303	3	Code 35BV
	338–3226–01	1	Slip On Connector Code 35BG,35BV	4	332–0819	1	Housing, Connector – Push On Code 35BY
	338-2522	1	Screw On Connector	5	332-2715	1	Terminal, Receptacle - Code
	338-3332	1	Slip On Connector				35BY
			Code 35BY - 4 Pin, 3 Wire -	6	332-2301	2	Tab, Faston
			Begin Spec E	7	332-0806	1	Terminal, Ring (#8) Code 35BY
	338–2841 338–3182	1	Screw On Connector Slip On Connector	8	323–1381	1	Housing, Receptacle – 4 Way Code 35BY

Wiring Harness




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	338–2075 338–3179 338–2390	1 1 1	Harness, Wiring – Engine 4 Wire, 4 Pin Connector – Code 35BB,35BH Screw On Connector Slip On Connector 2 Wire, 4 Pin Connector – Code 35CG Relocate Voltage Regulator Begin Spec E – Code	2 3 4 5 6 7	332–0806 332–2715 332–2715 323–1381 323–1382 332–0819 332–2301	1 5 3 1 1 1	Terminal, Ring(#8) Terminal, Receptacle (.250) Code 35BB, 35BH Code 35CG Housing, Receptacle – 4 Way Housing, Tab – 4 Way Housing, Receptacle Terminal, Tab 20 Ampere Charging System
	338–2846 338–3184 338–2834	1 1 1	35BB,35BH Screw On Connector Slip On Connector Relocate Voltage Regulator Begin Spec E – Code 35CG	8	332–1503 332–2973	1 2	35 Ampere Charging System Terminal, Spade (#8) Code 35BB,35BH

Wiring Harness Control Panel




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Harness, Wiring - Control	3	357-0030	1	Rectifier, LOPKO
			Panel	4	323-1216	1	Body, Connector – LOPKO
	338-2109	1	Without LOPKO	5	332-0942	2	Tie, Cable – LOPKO
	338-2108	1	Lopko	6			Terminal, Tab
1	323-0916	1	Connector		332-2301	4	20 Ampere Charging System
2	323-0987	1	Body, Connector		332-1503	2	35 Ampere Charging System

Ignition – Electronic



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	166–0761	1	Coil, Battery Ignition (Includes Nuts) (Spec B Thru G)	11	166–0787–01	1	Bracket, Coil Mounting (Spec B Thru G)
2	312-0256	1	Capacitor	12	815-0261	1	Screw, Hex Washer Head
3	166–0767	1	Rotor, Ignition				(1/4–20 x 1/2")
4	167-0272	2	Plug, Spark	13	166-0820	1	Coil, Battery Ignition (Begin
5	167-1602	1	Cable,Spark Plug				Spec H)
6	166-0770	1	Nut, Hex Flange (M4 Positive	14	518-0574	1	Clip (Begin Spec H)
			Terminal)	15	134-5130-02	1	Clamp, Coil Mounting (Begin
7	518-0515	1	Clip, Wire (Spec B thru G only)				Spec H)
8	166–0771	1	Nut, Hex Flange (M5 Negative Terminal)	16	815–0261	3	Screw, Hex Washer Head Thread Forming
9	114-0022	1	Screw, Cap – Hex Head (5/16–18 x 1–3/4")	17	821–0018	1	(1/4–20 x 1/2") Screw, Hex Lock
10	815–0650	2	Screw, Hex Washer Head (1/4–20 x 1")	•	32. 3310	•	(1/4–20 x 5/8")


Exhaust System



Exhaust System

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	542–7129	1	Kit, Exhaust Adapter (Includes Parts Marked ~) Code 21BG	24	821-0014	1	#Screw, Lock Head Flange (5/16–18 x 1/2")
2	800–0512	4	Screw ~ Cap, Hex Head (Special)	25	821-0029	1	#Screw, Lock Head Flange (3/8 x 3/4")
	800-0512-01	4	Cap, Hex Head (Special)	26	542-7119	1	Kit, Right Front Side or Left Rear
	802–0055	4	Socket Head (5/16–18 x 1") Code 21CB				Side Manifold (Includes Parts Marked *)
3			Washer	27	154-1610-50	1	*Manifold, LH Exhaust
	850-0045	4	~Lock (5/16") Code 21AG,21BG				(Shown)
	740–1006	4	Flat (M8) Code 21AZ,21CC	28	155–1219	2	*Clamp, Muffler
	526–0022	4	Flat (5/16" Screw) Code 21CB	29	805–0019	2	*Screw, Hex Head Cap
4	154–1484–50	2	~Adapter, Exhaust (Flange Type)				(3/8–16 x 1 7/16")
			Code 21AG,21BG	30	862–0003	2	*Nut, Hex (3/8-16)
5	154–2747	2	~Gasket, Exhaust Manifold	31	542-7120	1	Kit, Left Front Side or Right Rear
6	155–2534	2	Muffler (Use in Pairs) – Use With Adapter 154–1484–50				Side Manifold (Includes Parts Marked +)
7	155-1239	2	Clamp, Muffler (1-1/8" Dia.)	32	154-1609-50	1	+Manifold, RH Exhaust
8	154-1484-50	2	Adapter, Exhaust Manifold				(Not Shown)
			4–1/4" Long	33	155–1219	2	+Clamp, Muffler
9	541-0419	1	Kit, Exhaust Cover & Support	34	805-0019	2	+Screw, Hex Head Cap
			(Includes Parts Marked ^)				(3/8-16 x 1 7/16")
			Code 21CC	35	862-0003	2	+Nut, Hex (3/8-16)
10	134–4656–50	1	^Cover, Exhaust Tube – RH Code 21AZ,21BB – Painted	36	542–7101	1	Kit, Pepper Pot Muffler (Includes Parts Marked @)
11	134–4678–50	1	^Cover, Exhaust Tube – LH Code 21AZ,21CC – Painted	37	155–1216	2	@ Muffler (Use With Exhaust Adapter 1545–1484–50–
12	134-4981-50	1	^Support, Exhaust Cover				(Code 21BG)
13	850-0050	2	^Washer, Lock (3/8")	38	155-1219	2	@ Clamp, Muffler
14	821-0008	2	^Screw, Lock Head – Flange	39	805-0019	2	@ Screw, Hex Head Cap
			(1/4–20 x 5/16")				(3/8-16 x 1 7/16")
15	800-0048	2	^Screw, Cap – Hex Head	40	862-0003	2	@ Nut, Hex (3/8-16)
			(3/8-16 x 3/4")	41	542-7122	1	Kit, Front or Rear Outlet Muffler
16			Tube, Exhaust – RH – Painted				(Includes Parts Marked <)
	154-2263-50	1	Code 21AZ,21CC,21BD	42	155-1686	1	<muffler, (use="" exhaust="" td="" with<=""></muffler,>
	154-2112-50	1	Code 21CB				Exhaust Adapter
17			Tube, Exhaust – LH – Painted				154-1484-50 (Code 21BG)
	154-2265-50	1	Code 21AZ,21CC,21BD	43	155-1219	2	<clamp, muffler<="" td=""></clamp,>
	154-2113-50	1	Code 21CB	44	805-0019	2	<screw, cap<="" head="" hex="" td=""></screw,>
18			Kit, Muffler (Includes Parts				(3/8–16 x 17/16)
			Marked #)	45	862-0003	2	<nut, (3="" 8–16)<="" hex="" td=""></nut,>
	541-0315	1	Outlet, RH				, ,
	514-0316	1	Outlet, LH)				
19			#Muffler, Exhaust	~-	Parts included	in Exh	aust Adapter Kit.
	155-2245-01	1	RH – Outlet (Not Shown)	^ _	Parts included	in Exh	aust Cover & Support Kit.
	155-2245-02	1	LH – Outlet (Shown)				and LH Outlet Muffler Kits.
20	154-2747	2	#Gasket, Exhaust Manifold				Rear Crossover Manifold Kit.
21	155-2419-02		#Bracket, Muffler	+-			ht Rear Crossover Manifold Kit.
22	800–0512	4	#Screw, Hex Head Cap (Special)	@- <-	Parts included	in Per	oper Pot Muffler Kit. nt or Rear Outlet Muffler Kit.
23	850–0045	4	#Washer, Lock (5/16) Code 21AG,21BG	•			

Fuel Pump



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0707	1	Hose	4	503-0707	1	Line, Pulse (Cut To 7" Long)
2			Pump, Fuel – Vacuum 2 Open Ports	5	502-0395	1	Connector, Hose – Fuel Pump Vacuum
	149-2187-02	1	All Codes Except 23DN	6	149-1321	1	Cap, Fuel Fitting
	149-2187-01	1	Code 23DN	7	503-0301	1	Clamp, Hose
3	815-0555	2	Screw, Tapping - Pan Head	8	503-0731	6	Clamp, Hose (1/2")
			(10–24 x 5/8")	9	149-2206-01	1	Filter, Fuel

Labels, Paint, Thread Sealant and Gasket Kits

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	518–0452	1	Sealant, Thread (50cc Bottle)		168–0191	1	Kit, Gasket – Engine Complete
	518-0347	1	Loctite, Bottle (250cc)				(Includes Parts Marked +)
			Label, Performer 24 XSL		101-0782	1	+Gasket, Bearing Plate - 1/64"
			Red, White		102-1387	1	+Gasket, Oil Base
	98-6802-04	3	Code 19AS		103-0810	1	+Gasket, Gear Cover
	98-6802-04	2	Code 19AV		110-3575	3	+Gasket, Valve Box Cover
	98-6664	1	Label, Air Cleaner Maintenance		110-2987	2	+Gasket, Cylinder Head
	525-0394	1	Paint, Enamel (Touch-Up) -		120-0161	1	+Gasket Kit, Oil Pump
			Flat Black, Pressurized Can (16 oz.)		122–0771	1	+Gasket, Oil Filter Adapter to Block
			Label, Periodic Maintenance		110-3604	2	+Seal, Intake Valve
	98-5969-02	1	Standard Capacity Oil Base		509-0142	1	+Seal, Oil Fill Cap O-Ring
	98-5969-04	1	High Capacity Oil Base		102-0743	1	+Gasket, Oil Drain
	98-5735	1	Decal, Control Panel		509-0145	1	+Seal, Air Cleaner O-Ring
	98-4024	2	Label, Head Bolt Torque –		154-0733	1	+Gasket, Carburetor Flange
			Begin Spec C		154-2219	2	+Gasket, Intake Manifold
	98-6266	1	Label, Maintenance (Oil Check)		154-2747	2	+Gasket, Exhaust Adapter
	98-7193	1	Tag, 3 Year Warranty		160-1368	1	+Gasket, Breaker Box
	98-7295	4	Label, Barcode		509-0008	1	+Seal, Governor Shaft
	517-0165	1	Cap, Plug		509-0040	1	+Seal, Oil – Gear Cover
	168-0190	1	Kit, Gasket – Carbon Removal		509-0041	1	+Seal, Oil – Bearing Plate
			(Includes Parts Marked *)		509-0117	1	+Seal, Breather Cap O-Ring
	110-3575	3	*Gasket, Valve Compartment		145-0438	1	+Gasket, Carburetor
			Cover		154–2746	2	+Gasket, Exhaust Adapter
	110–2987	2	*Gasket, Cylinder		110-3604	2	+Seal, Oil – Valve
	154–2219	2	*Gasket, Intake Manifold		509-0269	1	+Seal, Fill Tube
	154–2747	2	*Gasket, Exhaust Adapter				
	154–2746	2	*Gasket, Exhaust Adapter				
	154–2747	2	*Gasket, Exhaust Manifold	* _			–0190 Gasket Kit.
	110–3604	2	*Seal, Oil – Valve	+-	Parts Include	d in 168	–0191 Gasket Kit

SALES OPTION CODE NUMBERS	10684 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35AU 35BB 45BB 45BB 45BW 47AL 47AR 47BA 47BB	10704 11AH 11AW 13BJ 13BP 13BW 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 35AU 35BB 45BB 47BA 47BA	11AH 11AW 13BG 13BK 13CE 15BL 15BL 17CE 17CF 17CF 17CF 21BG 23DC 31AY 31AZ 35AV 35BE 45BE	11AH V 11AV 13BC 13BC 13BC 13BC 15BC 15BC 15BC 17CC 17CC 17CC 17CC 17CC 17CC 17CC 17	H 11A N 11A N 11B N 13E N 13E N 13E N 15E N 15E N 15E N 17C	H 11 W 11 E 13 S 14 S 15 S 15 S 15 S 17 C	AH 1 AW 1 BBJ 1 BBN 1	1AH 1AW 3BJ 3BM 3BV 5BA 5BD 5BK 7CD 7CF 7DA 9AS 3DC 1AY 1AZ 3AT 5AU 5BC 5BB 5BW 7AR 7BA	11AH 11AW 13BJ 13BN 13BV 15BB 15BD 15BK 17CD 17CF 17DA 19AS 23DC 31AY 33AT 35AV 35BB 45BB 45BW 47AR 47BA	11AH 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35CH 45BE 45BW 47AR	10727 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35CH 45BT 47AR 47AZ 47BB 47BF	10792 11AH 11AW 13BV 13CB 13CD 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 23DN 31AY 31AZ 33AT 35AV 35BC 39AG 45BF 45BM 47AR 47AB	10803 11AH 11AW 13BJ 13BP 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35CG 45BB 47AR 47BA 47BB
SALES OPTION CODE NUMBERS	11AH 11AW 11BG 13BJ 13BN 13BW 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35AU 35BH 35BL 45BY 47AR 47BA	10814 11AH 11AW 13BK 13BP 15BD 15BJ 15BL 15BV 17CD 17CF 17DA 19AU 21BR 23DC 31AY 31AZ 33AT 35AU 35BB 45BB 47AR 47BB 47BF	10825 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31BC 33AT 35AV 35BC 45BB 45BW 47AR 47BA 47BB	10828 11AH 11AW 13BM 13BV 13CD 15BD 15BK 15BL 17CD 17CF 17DA 19AV 23DC 31AY 33AT 35BC 39AG 45BB 47AR	10829 11AW 11BE 13BR 13CG 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35AV 35BB 45BT 47AR 47BA 47BB	10833 11AH 11AW 13BJ 13BN 13BU 15BD 15BJ 15BL 17CF 17DA 17DF 19AV 23DC 31AY 35AU 35AU 35BC 45BD 47AR 47BA 47BB	10834 11AH 11AW 13BJ 13BM 13BV 15BD 15BJ 15BL 17CD 17CF 17DA 19AV 23DC 31AY 35AU 35AU 35BB 45BB 47AR 47BA	11AR 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS	11AW 11BE 13BJ 13BW 13BV 15BD 15BK 15BL 17CD 17CD 17CD 17DA 19AV 23DC 31AY 31AZ 33AT 35CH 45BT	11AH 11AW 13BM 13BV 13CD 15BD 15BK 15BL 17CD 17CF 17DA 19AU	10838 11 AW 11 BE 13 BM 13 BV 13 CD 15 BB 15 BD 15 BK 17 CD 17 CF 17 DA 19 AS 23 DC 23 DE 31 AY 31 AZ 33 AT 35 BC 39 AG 45 BT 47 AR 47 AZ 47 BB	10839 11AH 11AW 13BJ 13BN 13BV 15BD 15BJ 15BL 17CD 17CF 17DA 19AU 23DC 31AY 31AZ 33AT 35AH 35BY 45BB 47AR 47BA 47BB	10841 11AH 11AW 13BJ 13BM 13BU 15BD 15BK 15BL 17CD 17CF 17DA 19AU 23DC 31AY 31AZ 33AT 35AV 35BC 45BD 47AR 47BA 47BB

SALES OPTION CODE NUMBERS	10842 11AH 11AW 13BJ 13BZ 13CB 15BD 15BK 15BL 17DA 17DF 19AS 21CB 23DC 31AY 31BD 33AT 45BB 45BW 47BA 47BB	10843 11AH 11AW 13BJ 13BM 13BV 15BD 15BJ 15BL 17CD 17CF 17DA 19AU 23DC 31AY 35AV 35AV 35BC 45BT 47AR 47BB	10847 11AH 11AW 13BM 13BV 13CD 15BD 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35BC 39AG 45BB 47AR 47BA	10875 11AH 11AW 13BG 13BJ 13BZ 15BD 15BJ 15BM 17CF 17CV 17DA 19CJ 21CC 23DC 23DC 23DJ 23DK 31AY 31AY 31AZ 33AT 35BC 35BL 45BE 47AR 47BA	10890 11AH 11AW 13BJ 13BM 13BV 15BB 15BD 15BK 17CF 17DA 17DF 19AS 23DC 31AY 31BD 33AT 45BB 47AR 47AZ 47BB	10909 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 17CF 17DA 17DF 19AV 23DC 31AY 31AZ 33AT 35AU 35BB 45BE 47AR 47BB	10912 11AH 11AW 13BJ 13BM 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AU 23DC 23DN 31AY 31AZ 33AT 35AV 35BC 39AG 45BE 47AR 47BB	10913 11AH 11AW 11BG 13CG 13CH 13CS 15AZ 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31AY 35AT 35AV 35BH 45BF 47AR 47BB	10922 11AH 11AW 13BJ 13BW 13CM 15AZ 15BD 15BK 17DA 17DF 19AS 21BG 23DC 31AY 31AZ 33AT 35CH 45BB 45BW 47AR 47BA	10925 11AH 11AW 13BM 13BV 13CD 15BD 15BL 17CD 17CF 17DA 19AU 23DC 23DJ 23DJ 23DN 31AY 31AY 35BC 39AG 45BB 47AR 47BA	10966 11AH 11AW 13BJ 13BY 13CR 15BD 15BJ 15BL 17CF 17DN 19AU 23DC 31AY 31AZ 33AT 35AH 35BL 35BY 45BB 47AR 47BA	10967 11AH 11AW 13BR 13CD 13CE 15BD 15BK 15BL 17CD 17CF 17DA 19AU 21AZ 23DC 23DN 31AY 31AY 35AC 33AT 35BC 39AG 45BB 45BW 47AR 47BB	10983 11AH 11AW 13BJ 13BM 13BZ 15BB 15BD 15BK 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35AV 35BB 45BB 47AR 47BA
SALES OPTION CODE NUMBERS	10987 11AH 11AW 11BE 13BP 13CG 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31AZ 33AT 35AV 35BB 45BU 47AR 47BA 47BB	10999 11AH 11AH 13BG 13BJ 13BZ 15AZ 15BD 15BJ 15BZ 17CF 17CV 17DN 19AU 23DC 23DJ 23EJ 31AY 31AZ 33AT 35AV 35BZ 45BD 47AL 47BA	11014 11AW 11BE 13BG 13BJ 13BV 15BD 15BK 15BL 17CF 17CV 17DA 19AS 21BG 23DC 31AY 31AZ 33AT 35AU 35BC 45BT 47AR 47BA 47BB	11015 11AH 11AW 13BJ 13BS 13BY 15BD 15BJ 15BL 17CD 17CF 17DA 19AU 23DC 31AY 31AZ 33AT 35AH 35BL 35BY 45BB 47AR	11021 11AH 11AW 13BM 13BV 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AU 23DC 31AY 31AZ 33AT 35BC 35BV 35CK 45BB 47AR 47AZ 47BB	11022 11AH 11AW 13BK 13BN 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 45BE 47AR 47BA 47BB	11025 11AH 11AW 13BJ 13BM 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35AV 35BC 45BE 45BW 47AR 47BA 47BB	11029 11AH 11AW 13BJ 13BN 13BV 15BD 15BJ 15BL 17CD 17CF 17DA 19AS 23DC 23DJ 23DN 31AY 31BC 33AT 35AV 35BC 45BB 45BW 47AR 47BA 47BB	11041 11AH 11AW 13BJ 13BM 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31BD 33AT 45BB 47AR 47BA 47BB	11043 11AH 11AH 13BM 13BV 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AV 23DC 23DJ 23DN 31AY 31AZ 33AT 35BC 35CK 45BB 47AR 47AZ 47BB	11050 11AW 13BJ 13BM 13BV 15BB 15BD 15BK 17CD 17CF 17DA 19AS 23DC 23ED 31AY 31AZ 33AT 35AV 35BC 45BT 45EC 47AR 47BA 47BB	11057 11AH 11AW 11BE 13BM 13BV 13CD 15BD 15BL 17CD 17CF 17DA 19AS 23DC 23DN 31AY 31AZ 33AT 35BC 39AG 45BS 47AR 47AZ 47BB	11066 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35BG 35BV 35CH 45BB 45BW 47AR 47BA 47BB

SALES OPTION CODE NUMBERS	11070 11AH 11AW 13BJ 13BM 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 31AZ 33AT 35AV 35BC 45BB 47AR 47BA 47BB	11071 11AH 11AW 11BE 13BJ 13BM 13BV 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 35AV 35BC 45BS 47AR 47BA 47BB	11087 11AH 11AW 13BJ 13BN 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 31AY 35AV 35AV 35BC 45BB 45BW 47AR 47BA 47BB	11092 11AH 11AW 13BJ 13BN 15BD 15BK 15BL 17CD 17CF 17DA 19AS 23DC 23DN 31AY 35AV 35BC 45BE 45BW 47AR 47BA 47BE	11109 11AH 11AW 13BN 15BB 15BD 15BK 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35AV 35BC 45BE 45BW 47AR 47BA 47BB	1111 11AH 11AW 11BE 13BS 13CG 15BD 15BK 15BL 17CF 17DA 17DF 19AS 21BG 23DC 31AY 35BV 35CC 45BS 47AR 47BA 47BB	11115 11AH 11AW 13BN 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AU 23DC 31AY 35AZ 35AV 35BZ 35CK 45BB 47AR 47AZ 47BB	11116 11AH 11AW 13BJ 13BN 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35BV 35CC 45BB 45BW 47AR 47BA	11117 11AH 11AW 13BM 13BV 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AS 21BG 23DC 31AY 35AV 35AV 35BC 45BE 45BW 47AR 47AZ 47BB	11119 11AH 11AW 11PP 13CB 15AZ 15BD 15BK 17CF 17DF 17DN 19AS 19BB 23DC 23DJ 23ED 31AY 31AZ 33AT 35AV 35BH 45BF 47AR 47BE	11125 11AH 11AW 13BJ 13BN 15BD 15BK 15BL 17CF 17DA 17DF 19AS 21BG 23DC 31AY 31AZ 33AT 35CH 45BE 45BW 47AR 47BA 47BE 47BF	11133 11AH 11AW 13BN 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AS 21BG 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BC 35CK 45BB 45BW 47AR 47AZ 47BB	11138 11AH 11AW 13BJ 13BM 13BV 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 31AY 35BC 45BE 45BW 47AR 47BA 47BB
SALES OPTION CODE NUMBERS	11146 11AH 11AW 13BK 13BM 13BU 15BD 15BJ 15BL 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AW 35AV 35BC 45BB 47AR 47BB	11150 11AH 11AW 13BJ 13BN 13BV 15BB 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35BV 35CC 45BB 45BW 47AR 47BA 47BG	11151 11AH 11AW 13BN 13CG 15BD 15BJ 15BL 17CF 17DA 17DF 19AS 23DC 23DJ 23ED 31AY 31AZ 33AT 35AV 35BC 45CC 47AR 47AZ 47BB 47BF	11155 11AH 11AW 11BE 13BG 13BJ 13BV 15BD 15BK 15BL 17CF 17CV 17DA 19AV 21BG 23DC 31AY 31AZ 33AT 35AU 35BC 45BT 47AR 47BA 47BB	11157 11AH 11AW 13BP 13CG 15BD 15BK 15BL 17DA 17DF 19AS 21BG 23DC 23DJ 23DN 31AY 31AZ 33AT 35CH 45BB 47AR 47BA 47BB	11158 11AH 11AW 11BF 13BJ 13BM 13BV 15BB 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23ED 31AY 31AZ 33AT 35CH 45BT 47AR 47BA 47BB	11166 11AH 11AW 13BP 13CG 15BD 15BK 15BL 17DA 17DF 19AS 21BG 23DC 23DJ 23DN 31AY 31AZ 33AT 35CH 45BE 47AR 47BA	11167 11AH 11AW 11BG 13BM 13BV 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AU 23DC 31AY 31AZ 33AT 35BC 35BV 35CK 45BB 47AR 47BH	11168 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CD 17DA 19AV 23DC 31AY 31AZ 33AT 35AU 35BH 45BB 45BW 47AR 47BA 47BB	11175 11AH 11AW 11BF 13BN 13BV 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 21BG 23DC 23DN 31AY 31AZ 33AT 35AV 35BC 35CK 45BT 47AR 47AZ 47BB 47BF	11181 11AH 11AW 13BM 13BV 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AV 23DC 23DJ 23DN 31AY 31AZ 33AW 35AV 35BC 35CK 45BB 47AR 47AZ 47BB	11183 11AH 11AW 13BJ 13BZ 13CB 15BD 15BJ 15BM 17CF 17CV 17DA 19CJ 21CC 23DC 23DJ 23DK 31AY 31AZ 33AT 35AU 35BC 45BE 47AR 47BA 47BB	11184 11AH 11AH 13BJ 13BN 13BV 15BB 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BC 45BB 45BW 47AR 47BA 47BG

SALES OPTION CODE NUMBERS	11185 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 15BL 17CF 17DA 17DF 19CL 23DC 23DC 23DN 31AY 31BC 33AW 35AU 35BZ 45BB 45BW 47AR 47BA 47BB 47BF	11189 11AH 11AW 11BF 13BN 13CG 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31BC 33AT 35BV 35CC 45BT 47AR 47AZ 47BB 47BF	11190 11AH 11AW 11BF 13BF 13BN 13CE 15AZ 15CK 15CK 15CR 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 35BV 35CC 45BT 47AR 47AZ 47BB 47BF	11194 11AH 11AW 13BN 13BV 13CD 15BD 15BK 15BL 17BY 17DA 17DF 19AS 21BG 23DC 23DN 31AY 31AZ 33AT 35CJ 35CK 45EA 47AR 47AZ 47BB 47BF	11196 11AH 11AW 13BK 13BM 13BV 15BD 15BJ 17CF 17DA 17DF 19AS 23DC 31AY 35AU 35BB 45BB 45BW 47AR 47BA 47BB	11200 11AH 11AW 13BJ 13BN 13BV 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BC 45BB 45BW 47AR 47BA 47BG	11202 11AH 11AW 13BJ 13BP 13BV 15BA 15BD 15BK 17BY 17CK 17DA 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 33BB 35AU 35BC 45BE 47AR 47BB 47BF	11205 11AH 11AW 13BJ 13BN 13BV 15BC 15BF 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35BV 35CC 45BB 45BW 47AR 47BA 47BB	11210 11AH 11AW 13BK 13BM 15BD 15BJ 15BL 17BZ 17CV 17DA 19AS 23DC 23DJ 23DN 31AY 35AV 35BC 45BB 47AR 47AZ 47BB	11214 11AH 11AW 11BG 13CB 13CG 15AZ 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BH 45BF 47AR 47BB	11216 11AH 11AW 13BF 13BN 13CE 15AZ 15EX 15CR 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31BC 33AT 35BV 35CC 45BB 47AR 47AZ 47BB 47BF	11219 11AH 11AW 11BG 13BM 13BV 13CD 15BD 15BL 17CF 17DA 17DF 19AU 23DC 31AY 31AZ 33AT 35BC 35BV 35CK 45BB 47AL 47AR 47BH	11222 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 35AV 35BC 45BB 45BW 47AR 47AZ 47BB 47BF
SALES OPTION CODE NUMBERS	11223 11AH 11AW 11BK 13BG 13BJ 13BV 15BD 15BL 15CK 17BZ 17CV 17DA 19AS 23DC 31AY 31BC 33AW 35AU 35BC 45BB 47AR 47BA 47BB	11225 11AH 11AW 13BJ 13BM 13BV 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31BC 33AT 35AV 35BC 35CK 45BE 45BW 47AR 47AZ 47BB	11228 11AH 11AW 13BJ 13BN 13BV 15BK 15BL 15CU 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35BV 35CC 45BB 45BW 47AR 47BA 47BB	11229 11AH 11AW 13BJ 13BZ 13CB 15AZ 15BD 15BK 15BZ 17DA 17DF 19AS 21CB 23DC 31AY 31BD 33AT 45BB 45BW 47AR 47BA	11256 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35CH 45BB 45BW 47AR 47BB 47BF	11257 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35CH 45BE 45BW 47AR 47BB 47BF	11258 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35CH 45BS 47AR 47BB 47BF	11259 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35CH 45BU 47AR 47AZ 47BB 47BF	11260 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35CH 45BT 47AR 47AZ 47BB 47BF	11275 11AH 11AW 13BF 13BN 13CG 15BB 15BD 15BK 17CF 17CV 17DA 19AS 23DC 31AY 31AZ 33AT 35AV 35CC 45BE 45BW 47AR 47BA 47BB	11278 11AH 11AW 13BJ 13BZ 13CB 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31BD 33AT 45BB 45BW 47AR 47BA	11289 11AH 11AW 13BG 13BJ 13BZ 15AZ 15BD 15BJ 15BZ 17CF 17CV 17DN 19AU 23DC 23DJ 23EJ 31AY 31AZ 33AT 35AV 35CT 45BD 45AL 47AR 47BA	11292 111AH 11AW 13BN 13BV 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31AZ 33AT 35AV 35BC 35CK 45BB 47AR 47AZ 47BB 47BF

SALES OPTION CODE NUMBERS	11295 11AH 11AW 13BZ 13CB 13DD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31BD 33AT 45BB 45BW 47AR 47BA	11306 11AH 11AW 13BN 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31AZ 33AT 35CJ 35CK 45BE 45BW 47AR 47AZ 47BB 47BF	11314 11AH 11AH 11BH 13BF 13CB 15CG 15AZ 15BD 15BK 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35BV 35CC 45BF 47AR 47AZ 47BB 47BF	11318 11AH 11AW 11BE 13BG 13BJ 13BV 15BD 15BK 15BL 17CF 17CV 17DA 19AV 21BG 23DC 31AY 35BC 45BT 47AR 47BA 47BB	11331 11AH 11AW 13BJ 13BN 15BB 15BD 15BK 17CF 17CV 17DA 19AS 23DC 31AY 35AV 35AV 35AV 45BE 45BW 47AR 47BA 47BB	11338 11AH 11AW 13BJ 13BN 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BC 35CK 45BB 45BW 47AR 47AZ 47BB 47BF	11363 11AH 11AW 13BN 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AV 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BZ 35CK 45BE 45BW 47AR 47AZ 47BB 47BF	11367 11AH 11AW 13BN 13CG 15BC 15BD 15BK 15BZ 17CF 17CK 17DA 19AU 23DC 31AY 31AZ 33AT 35BC 45BE 45BW 47AR 47AZ 47BB	11384 11AH 11AW 13BN 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BC 35CK 45BB 45BW 47AR 47AZ 47BB 47BF	11398 11AH 11AW 13BN 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 21BG 23DC 23DN 31AY 31AZ 33AT 35AV 35DB 45BB 45BW 47AR 47AZ 47BB 47BF	11431 11AH 11AW 13BJ 13BN 15BB 15BK 15BU 17BZ 17DA 17DF 19AS 21BG 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BC 45BE 45BW 47AR 47BB 47BF	11434 11AH 11AW 13BP 13BZ 13DD 15AZ 15BD 15BJ 15BZ 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31BD 33AT 45BB 45BW 47AR 47BA 47BB	11436 11AH 11AW 13BK 13BM 13BU 15BD 15BJ 15BL 17CV 17DA 19AS 23DC 23DJ 23DN 31AY 35AV 35AV 35BC 45BB 47AR 47AZ 47BB
SALES OPTION CODE NUMBERS	11468 11AH 11AW 13BF 13BZ 13CG 15AZ 15BD 15BZ 15CK 17CV 17DZ 19AU 23DC 23DJ 23EJ 31AY 31AZ 33AT 35AV 35CT 45BD 47AL 47AR	11469 11AH 11AW 13BN 13BV 13CD 15BA 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35DB 45BE 45BW 47AR 47AZ 47BB 47BF	11471 11AH 11AW 11BF 13BM 13BV 13CD 15BD 15BK 15BL 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AW 33AV 35DB 45BT 47AR 47AZ 47BB 47BF	11480 11AH 11AW 13BM 13CG 15BC 15BC 15BK 17BZ 17CV 17DA 19AV 23DC 23DJ 23ED 31AY 31AZ 33AT 35AV 35BB 45BF 47AR 47AZ 47BB 47BF	11481 11AH 11AW 13BM 13BV 13CD 15AZ 15BD 15BK 15BZ 17CF 17CV 17DA 21BG 19AS 23DC 23DN 31AY 31AZ 33AT 35AV 35DB 45BB 47AR 47AZ 47BB 47BF	11487 11AH 11AW 11BG 13CB 13CG 15BF 17CF 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35BH 45BF 47AR 47AZ 47BB	11490 11AH 11AW 11BE 13BG 13BJ 13BV 15BD 15BK 15BL 17CF 17CV 17DA 19AV 21BG 23DC 31AY 31BC 33AT 35BV 35CC 45BT 47AR 47BA 47BB	11493 11AH 11AW 13BN 13BV 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 23DN 31AY 31AZ 33AT 35DJ 35CK 45BW 45EA 47AR 47BB 47BF	11495 11AH 11AW 13BJ 13BW 13CM 15AZ 15BD 15BK 15BZ 17DF 17DZ 19AS 23DC 31AY 31AZ 33AT 35CH 45BB 45BW 47AR 47BA 47BB	11570 11AH 11AW 13BN 13BV 13CD 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 21BG 23DC 23DN 31AY 31AZ 33AT 35CJ 35CK 45BW 45EA 47AR 47BB 47BF	11582 11AH 11AW 13BJ 13BN 13BV 15AZ 15BD 15BK 15BZ 17CF 17DA 17DF 19AS 23DC 31AY 31AZ 33AT 35CH 45BW 45EA 47AR 47BB 47BF	11583 11AH 11AW 13CD 13CE 13GJ 15BF 17BZ 17DA 17DF 19AU 21BG 23DC 23DN 31AY 31BC 33AW 35AV 35BC 45BE 47AR 47AZ 47BB	11590 11AH 11AW 13BF 13BN 13CG 15AZ 15BD 15BZ 15CK 17BZ 17CV 17DA 19AS 23DC 23DJ 23DN 31AY 31BD 33AT 35AV 35CH 45BE 47AR 47BB 47BF

SPEC NO.	11607 11AH 11AW 13BM 13BV 13CD 15BD 15BK	11613 11AH 11AW 13BM 13BV 13CD 15BD 15BK
SALES OPTION CODE NUMBERS	15BL 17BY 17DA 17DF 19AS 23DC 23DJ 23DN 31AY 31AZ 33AT 35AV 35DB 45BD 45BW 47AR 47AZ 47BB 47BF	15BL 17BY 17DA 17DF 19AU 23DC 23DN 31AY 31AZ 33AT 35AV 35DB 45BE 47AR 47AZ 47BB 47BF

SALES OPTION CODE DEFINITIONS

LISTED BELOW ARE SALES OPTION CODE NUMBERS USED ON P224G

11AH	Standard Bearing Plate	17DZ	Base, Oil – 3 Quart – Side Drain – Steel Plug
11AW	Premium Block with Standard Thrust	19AS	Air Cleaner – Standard Capacity
	Washer	19AU	Air Cleaner – High Capacity
11BE	Adapter, Hydraulic Pump (SAE A)	19AV	Remote Air Cleaner Adapter
		19BB	·
11BF	Adapter, Hydraulic Pump (SAE B)		Air Cleaner Cover – Chrome
11BG	6 Holes Rear of Block	19CJ	Remote Air Cleaner Adapter with Elbow
11BH	Adapter, Bearing Plate (7" Pilot)	19CL	Air Cleaner – High Capacity
11BK	Pulley, Single Groove	21AZ	Exhaust Tubes (14" Centers) with Covers
13BF	Governor, 2-Speed Solenoid	21BG	Exhaust Adapter (1.5" OD)
13BG	Governor–3450 High Idle	21BR	Exhaust System (Steiner)
13BJ	Side Pull Governor	21CB	Exhaust Tubes (13.24" Centers)
13BK	Front Pull Governor	21CC	Exhaust Tubes with Covers and Support
13BM	3850 High Idle		Brackets (14" Centers)
13BN	3600 High Idle	23DC	Blower Wheel
13BP	3300 High Idle	23DE	Stationary Guard – No PTO (Steel)
13BR	3200 High Idle	23DJ	No Rotating Screen
13BS	2800 High Idle	23DK	Cylinder Air Housings with Weld Nuts
13BU	1100 Low Idle	23DN	Stationary Guard (No PTO-Plastic) -
13BV	1200 Low Idle	LODIN	Onan Logo
		0055	
13BW	1300 Low Idle	23ED	Stationary Guard with PTO (Plastic)
13BY	1400 Low Idle	23EJ	Stationary Guard without P.T.O. – No Logo
13BZ	1500 Low Idle	31AY	Electronic Ignition
13CB	3780 High Idle	31AZ	Alternator – 12V/20A
13CD	No Governor Linkage	31BC	Alternator – 12V/35A
13CE	1800 Low Idle	31BD	No Alternator
13CG	Fixed Speed Governor	33AT	Starter Solenoid Shift (Side) Standard
13CH	10 Ball Governor	33AW	Starter–Solenoid Shift (Side) Premium
13CM	3400 RPM High Idle	33BB	No Starter Cap Kit
13CR	3550 RPM High Idle	35AH	Low Oil Pressure Switch (1 Terminal/Normally Open)
13CS	1850 High Idle	35AU	Low Oil Pressure Switch (1 Terminal/Normally
13DD	Governor, Side Pull, .190 Hole		Closed)
13DG	1950 Low Idle	35AV	Low Oil Pressure Switch (2 Terminal/Normally Open)
13GJ	Delete Governor	35BB	4 Pin Harness with Mating Connector
15AZ	Fuel Pump–No Filter (Dual Inlet)	35BC	6 Pin Harness with Mating Connector
15BA	Fuel Pump–Filter (Top Inlet)	35BG	Harness, 3 Wire – Leads
15BB	. , , ,	35BH	4 Pin Harness
	No Pump–Filter		
15BC	No Pump, No Filter	35BL	High Metal Temperature Switch (1 Terminal –
15BD	Downdraft Carb-Manual Choke		Normally Open)
15BF	Carb-LPG Downdraft	35BV	Low Oil Pressure Switch (3 Terminal – Normally
15BJ	Front Pull Choke		Open/Normally Closed Common Ground)
15BK	Rear Pull Choke	35BY	Harness, 4 Pin – 3 Wire
15BL	Fuel Pump with Filter (Dual Inlet)	35BZ	6 Pin Harness
15BM	Fuel Pump – No Filter (Top Inlet)	35CC	6 Pin with Diode and Mating Connector
15BV	Fuel Line (Hard) Assy	35CG	4 Pin/2 Wire with Mating Connector
		35CH	
15BZ	5" Fuel Line with Filter (Suck Side –		6 Pin/4 Wire with Mating Connector
. = 0	Bottom)	35CJ	6 Pin/4 Wire Harness
15CK	Choke, Remote (Solenoid)	35CK	Control Panel
15CM	Fuel Line 5" – Filter (SUC Side Top)	35CT	4 Pin Harness-w/Metri-Pack
15CR	Carb-Downdraft Dual Fuel	35DB	Control Panel
15CU	Carb-Downdraft-Manual Choke Intake Manf	39AG	Control Panel
	w/Plug-Special	45AL	Generator Adapter-YK
17BY	Oil Fill & Indicator – Inner	45BB	1.12 Diameter Straight Shaft 3.95 to RFB
	Oil Fill Tube & Indicator – Outer		
17BZ		45BD	1.44 Diameter Straight Shaft 3.77 to RFB
17CD	Oil Filter (3.4" Long)	45BE	1.44 Diameter Straight Shaft 3.99 to RFB
17CF	Oil Fill Tube & Indicator – Outer Extension	45BF	1.12 Diameter Tapered Shaft 3.11 to RFB
17CG	Base, Oil-Std Cap (Opt Drains)	45BM	6 Holes–Rear of Block
17CK	Plate, Oil–Remote Filter Adapter	45BS	Internal Splined 9 Tooth Crank
17CV	Oil Filter-Hex Nut (4.6" Long)	45BT	Internal Splined 13 Tooth Crank
17DA	Oil Base-3 Quart (Sandcast)	45BU	Internal Splined 11 Tooth Crank
17DF	Oil Filter (4.2" Long)	45BW	Crankshaft Key
17DN	Oil Base, Single Drain – 3 Quart		
17014	on baoo, onigio brain o daunt		

SALES OPTION CODE DEFINITIONS (cont'd)

LISTED BELOW ARE SALES OPTION CODE NUMBERS USED ON P224G

45BY	1.12 Diameter Straight Shaft 5.00 to RFB	47AZ	Nameplate - Alternate Location
45CC	Crankshaft-No PTO (Stub)	47BA	Nameplate – Standard Location
45EA	1.12 Diameter Straight Shaft 4.71 to RFB	47BB	Labels – P224
45EC	Adapter, Pump (SAE-B)	47BE	Labels – P224
47AL	No Labels	47BF	Maintenance Labels
47AR	Finishing List	47BG	Maintenance Labels
47AY	Loose Labels	47BH	Nameplate Location

Part No.	<u>Page</u>	Part No.	<u>Page</u>	Part No.	Page	Part No.	<u>Page</u>
098–4024, 5 5	5	103–0810, 17	, 55	110–3571, 7	,	120–0398, 9	a
098–4240, 9 ,		104–0043, 11		110–3572, 7		120-0491,	
20, 21, 31, 38		104–0091, 7 ,		110–3575, 7		120–0680,	
098–5735, 4 1	1, 55	104–0170, 12		110–3604, 7		120–1215,	
098–5969–02	2, 55	104–0575, 7	•	110–3616–0		120–1230,	
098–5969–04	4, 55	104–0776, 7		110–3655, 7		120–1272,	
098–6266, 5 5	5	104–0779, 12	2	110–3655–0		120–1275–	
098–6664, 55	5	104-0864-01		110-3655-0		122-0352-	•
098–6802–04	1 , 55	104–1310, 11		110–3655–1		122–0469,	•
098–7193, 5 5	5	104–1311, 11		110–3655–2		122–0502,	
098–7295, 5 5	5	104–1314, 11		112–0069, 9		122–0771,	
098–7315–07		104–1340, 11		112–0265, 9)	122–0800, ⁻	15
099–2393, 3 1	1	104–1500, 11		112-0265-0)1, 9	122–0814,	15
101–0405, 7		104–1694, 11		112-0265-0)2, 9	123-0951,	7
101–0430–01	-	104–1698, 11		112-0265-0)3, 9	123-0952,	7
101–0437–01		104–1786, 11		112-0265-0)5, 9	123-0954,	7
101–0439–01	1, 7	104–1808, 11		112–0267, 9)	123-0958,	7
101–0761, 9		104–1831, 11		112–0268, 9)	123–1417,	7
101-0766-01		105–0541, 10)	113–0296, 9)	123–1539,	20
101-0766-02		105–0594, 10)	113-0296-0)5, 9	123-1685-	50, 14
101–0782, 55		105–0676, 10)	113-0296-1	0, 9	123-1718-	50, 14
101-0793-02	2, 7	105–0700, 10)	113-0296-2	20, 9	123-1729-	50, 14
101–0804, 7	. =	110–0539, 7		113-0296-3	80, 9	123–1843,	14
101-0804-02		110–0639, 7		113–0311, 9)	123–1860,	14
101-0804-10	•	110–0893, 7		113-0311-0	1, 9	123-1860-0	01, 14
101-0804-20		110–0904, 7		113-0311-0	2, 9	123-1867-	51, 14
101-0804-30), <i>1</i>	110–1624–01	, 7	113-0311-0	3, 9	123-1869-	51, 14
101–0805, 7	. 7	110–1716, 7		113-0311-0	5, 9	123–1871,	20
101-0805-02		110–1716–02	2, 7	114–0022, 1	2, 51	123–1878,	14
101-0805-10	•	110–1716–05	, 7	114–0036, 7	•	123–1880, ⁻	14
101-0805-20	-	110–1716–10	, 7	114–0188, 7	,	123-1880-0	01, 14
101-0805-30	J, 7	110–1716–25	5, 7	114-0188-0	02, 7	123–1897–	51, 14
101–0809, 7) EE	110–1718, 7		114–0188–1	0, 7	123–1969–	51, 14
102–0743, 1 3		110–1719, 7		114–0188–2	20, 7	123–2091,	14
102–0938, 13		110–2987, 7 ,	55	114–0188–3	3 0, 7	123–2105,	14
102–1338, 13 102–1384–02		110–3167, 7		114–0203, 9)	134–0599,	
102–1384–02 102–1387, 13		110–3168, 7		115–0006, 7		134–4553–	50, 12
102–1367, 13		110–3549, 7		115–0025, 3		134–4656–	50, 53
103–0791, 17		110–3569, 7		120–0140, 9		134–4668–	•
100 0/00, 11	•	110–3570, 7		120–0161, 9	9, 55	134–4668–	51, 29

Part No. Page	Part No. Page	Part No. Page	Part No. Page
134–4678–50, 53	141–0281, 26 , 37	149–2187–01, 54	150–2531, 36
134–4680, 12	145–0438, 23 , 55	149–2187–02, 54	150–2545, 33
134–4689, 31	145–0522, 19	149–2206–01, 54	150–2553, 22 , 31
134–4689–01, 31	145–0614, 19	149–2242, 29 , 33	152–0155, 29 , 34
134–4689–02, 31	146–0331, 25	149–2385, 27	153–0500, 34 , 36
134–4846–50, 29	146–0338, 25	150–0075, 10	153–0514, 29 , 34 , 35
134–4846–51, 29	146–0339, 25	150–0078, 10	153–0523, 34
134–4850, 29	146–0423, 25	150–0621, 31	153–0524, 34
134–4981–50, 53	146–0424, 23 , 24	150–0639, 31	153–0606, 41
134–4986–02, 29	146–0426, 23 , 24	150–0694, 29	153–0632, 33
134–5001–50, 29	146–0431, 23	150–1187, 17	153–0642, 36
134–5127–02, 29	146–0433, 23 , 24	150–1214, 29	153–0678, 33
134–5130–02, 51	146–0435, 23 , 24	150–1269, 29	153–0686–02, 35
140–0721, 21	146–0437, 23 , 24	150–1366, 29	154–0733, 22 , 23 , 24 , 27 ,
140–0722, 21	146–0467, 23	150–1398, 29	55
140–0723, 21	146–0497, 22 , 24	150–1422–01, 17	154–1484–50, 53
140–1428, 20 , 21	146–0499, 24	150–1470–01, 17	154–1609–50, 53
140–1496–01, 19	146–0500, 23 , 24	150–1519, 10	154–1610–50, 53
140–1714, 20	146–0501, 23 , 24	150–1520, 10	154–2112–50, 53
140–1912–01, 19	146–0502, 24	150–1576, 29	154–2113–50, 53
140–1913–50, 19	146–0505, 23 , 24	150–1576–02, 29	154–2219, 22 , 37 , 55
140–2005–02, 19	146–0562, 26	150–1725–01, 29	154–2263–50, 53
140–2005–50, 19	146–0649, 25	150–1726–01, 29	154–2265–50, 53
140–2173, 21	146–0650, 25	150–1727, 29 , 33	154–2746, 55
140–2191–50, 19	146–0657, 25	150–1740, 29 , 33	154–2747, 53 , 55
140–2493–51, 19	146–0658, 25	150–1754, 41	154–2749, 22 154–2873, 22 , 26
140–2493–53, 19	146–0662, 22 , 25	150–1754–01, 29 , 41	
140–2536–01, 19	146–0681, 37	150–1755, 29 , 41	155–1216, 53 155–1219, 53
140–2536–02, 19	146–0695, 25	150–1761, 29	155–1219, 53 155–1239, 53
140–2539–51, 19	148–0941, 38	150–2184, 41	155–1686, 53
140–2539–53, 19	148–0973, 38	150–2264, 29 , 31	155–2245–01, 53
140–2628–01, 19	148–0974, 38	150–2364, 31	155–2245–01, 53
140–2628–02, 19	148–0975, 37 , 38	150–2388, 31	155–2419–02, 53
140–2722–01, 26 , 37	148–0976, 37 , 38	150–2409, 22	155–2534, 53
140–2722–02, 27	148–0981–02, 27	150–2478, 36	159–0020, 43
140–2761, 19	148–0984–02, 27	150–2480, 36	159–0595, 43
140–2786, 19	148–1025, 37	150–2481, 36	159–0596, 43
140–2794, 19	149–1299, 17	150–2498, 33	159–0597, 43
140–2860, 21	149–1321, 17 , 37 , 54	150–2499, 33	159–0981, 43
140–2942, 19	149–1828, 32	150–2504–01, 29	.50 0001, 40

Part No. Page	Part No. Page	Part No. Page	Part No. Page
160–1345–01, 9	301–9964–51, 41	332–1993, 32 , 47	338–3188–01, 47
160–1368, 9 , 55	307–2750, 36	332–2073, 47	338–3188–02, 47
166–0761, 51	307–2751, 36	332–2301, 47 , 48 , 49 , 50	338–3189, 47
166–0767, 51	307–2754, 37 , 38	332–2715, 47 , 48 , 49	338–3226–01, 48
166–0770, 51	307–2758, 33	332–2870–01, 47	338–3332, 48
166–0771, 51	308–0385, 41	332–2890, 47 , 48	338–3376, 47
166–0785, 17	308–0386, 41	332–2922, 47	338–3616, 47
166–0786, 17	309–0546, 45	332–2944, 47	357–0030, 47 , 50
166–0787–01, 51	309–0559, 9	332–2973, 47 , 48 , 49	403–4202–02, 29
166–0820, 51	309–0583, 45	332–3143, 47	501–0008, 15 , 43
167–0272, 51	309–0609, 45	332–3165, 47	502–0017, 15
167–1602, 51	309–0615, 45	338–2075, 49	502–0020, 15
168–0190, 7 , 55	309–0641–17, 45	338–2104–01, 47	502–0053, 45
168–0191, 7 , 55	309–0641–18, 45	338–2104–02, 47	502–0395, 54
190–0171, 42	309–0646–01, 45	338–2108, 41 , 50	502–1038, 22
190–0288, 42	309–0646–02, 45	338–2109, 41 , 50	502–1145, 37 , 38
190–0289, 42	309–0646–04, 45	338–2390, 49	502–1146, 26
190–0576, 12	309–0646–05, 45	338–2454, 48	503–0171, 20
190–0597, 42	312–0256, 19 , 20 , 51	338–2522, 48	503–0301, 17 , 54
190–0683, 12	321–0291, 47	338–2804–01, 47	503–0398, 20
190–0687, 12	323–0916, 47 , 50	338–2804–02, 47	503–0707, 54
191–1210, 12	323–0987, 47 , 50	338–2805, 47	503–0731, 22 , 54
191–1276, 17	323–1216, 47 , 50	338–2834, 49	503–1133, 19 , 22 , 26 , 27 ,
191–1456, 17	323–1381, 48 , 49	338–2841, 48	502 1141 20 21
191–1766, 40	323–1382, 47 , 49	338–2846, 49	503–1141, 20 , 21
191–1847, 17 , 29	323–1386, 47	338–2851–01, 47	503–1199, 22
191–1931, 40	323–1424, 47	338–2851–02, 47	503–1396, 20 503–1418, 22
191–1947, 39 , 40	323–1451, 47	338–2852–01, 47	503–1416, 22 503–1606–01, 19 , 22
191–1949–04, 39	323–1576, 47	338–2852–02, 47	503–1606–02, 19
191–1949–07, 39	323–1607, 47	338–2857, 47	503–1606–02, 19
191–1950, 40	332–0529, 32	338–3178–01, 47	503–1606–05, 27
191–1951, 40	332–0806, 47 , 48 , 49	338–3178–02, 47	503–1000–03, 27 503–1798–01, 26 , 27 , 37
191–1953, 40	332–0819, 47 , 48 , 49	338–3179, 49	503–1790–01, 20 , 27 , 37
191–1954, 40	332–0942, 50	338–3182, 48	503–1882–02, 19
191–1955, 40	332–1048, 47	338–3184, 49	503–1882–03, 19 , 26 , 37
191–1956, 40	332–1303, 47 , 48	338–3185–01, 47	503–1882–04, 27
191–2104, 17	332–1356, 26 , 27 , 37	338–3185–02, 47	504–0013, 43
191–2106, 29	332–1503, 47 , 49 , 50	338–3186, 47	505–0041, 43
191–2227, 29	332–1567, 47	338–3187–01, 47	505–0041, 43 505–0057, 43
301–0458, 19	332–1794, 26 , 37 , 38	338–3187–02, 47	505-0057, 45

Part No. Page	Part No. Page	Part No. Page	Part No. Page
505–0110, 13	517–0261, 29	541–0191, 29	740–1004, 9
505–0266, 13	517–0293, 17	541–0194, 41	740–1006, 22 , 26 , 53
505–1426, 15	518–0004, 22 , 31	541–0195, 47	750–1006, 39 , 40
505–1462, 13	518–0006, 36	541–0213, 29	800–0004, 9 , 21
508–0021, 19 , 31 , 33	518–0014, 11	541–0222, 12	800–0007, 7 , 29 , 33
508–0284, 41	518–0294, 9	541–0235, 45	800–0011, 7 , 27
508–0331, 31	518–0347, 55	541–0236, 45	800–0028–01, 15
509–0008, 17 , 55	518–0406, 17 , 31	541–0239, 9	800–0030–01, 12
509–0040, 17 , 55	518–0452, 55	541–0240, 41	800–0032–01, 17
509–0041, 7 , 55	518–0515, 29 , 41 , 47 , 51	541–0259, 17	800–0035, 22 , 26
509–0117, 7 , 55	518–0574, 51	541–0296, 31	800–0036, 22 , 26
509–0142, 14 , 55	520–0738, 42	541–0307, 12	800–0048, 53
509–0145, 20 , 55	520–0739, 42	541–0319, 45	800–0050, 41
509–0269, 14 , 55	520–0876, 7	541–0320, 20	800–0051–01, 7
509–0304, 14	520–0918, 7	541–0344, 9	800–0058, 22 , 26
510–0013, 17	520–0919, 7	541–0369, 31	800–0075, 42
510–0014, 17	520–0933, 17	541–0374, 9	800–0200–01, 13
510–0015, 10	520–0948, 19	541–0411, 39	800–0302–01, 13
510–0105, 17	525–0394, 55	541–0412, 36	800–0512, 53
515–0001, 10 , 11	526–0006, 29 , 33	541–0418, 33	800–0512–01, 53
515–0007, 12	526–0008, 36	541–0419, 53	800–0515, 9
515–0041, 42	526–0017, 12	541–0424, 29	800–0595, 39
515–0103, 11	526–0018, 21 , 26 , 27 , 29 ,	541–0433, 14	800–4072, 33
515–0146, 11	500,0004,00,00	541–0434, 14	801–0050, 9
515–0198, 11	526–0021, 29 , 33	541–0435, 14	802–0055, 53
515–0230, 11	526–0022, 53	541–0436–02, 45	803–0071, 9
515–0263, 11	526–0029, 41	541–0437–02, 47	805–0010, 9
515–0284, 12	526–0063, 7	541–0442, 38	805–0019, 53
516–0059, 29 , 33 , 34	526–0065, 15 , 17	541–0443, 38	809–0035, 7
516–0072, 7	526–0066, 9	541–0457–01, 19	813–0106, 20
516–0130, 17	526–0122, 22 , 26 , 39	541–0457–02, 19	813–0108, 43
516–0141, 7	526–0140, 34	541–0458–01, 19	815–0046, 17
517–0048–01, 7	526–0234, 19	541–0458–02, 19	815–0178, 20
517–0067, 7	526–0250, 7	541–0459, 19	815–0181, 31
517–0136, 29	526–0251, 13 , 22 , 26	541–0512, 37	815–0194, 15 , 29 , 41
517–0165, 55	526–0356, 12	542–7101, 53	815–0261, 31 , 51
517–0174, 31	526–0402, 7	542–7119, 53	815–0290, 29 , 36
517–0177, 33	541–0147, 21	542–7120, 53	815–0293, 37 , 38
517–0252, 31	541–0175, 47	542–7122, 53	815–0337, 29
517–0252–01, 20	541–0190, 34	542–7129, 53	815–0340, 17

Part No. Page	Part No. Page	Part No. Page	Part No. Page
045 0050 00 04 05	000 0000 50		
815–0359, 29 , 34 , 35	862–0003, 53		
815–0389, 19	862–0015, 17		
815–0391, 29	865–0020, 19		
815–0436, 29	865–0029, 19		
815–0439, 29 , 33	870–0053, 36 , 43		
815–0463, 19 815–0470, 19	870–0065, 21		
815–0474, 29 , 41 , 47	870–0131, 31 870–0212, 33 , 36		
815–0480, 36	870–0212, 33 , 30		
815–0510, 29	870–0298, 36		
815–0555, 54	870–0236, 30		
815–0563, 29	870–0399, 19		
815–0575, 19 , 31	870–0410, 14		
815–0576, 14	98–4240, 12		
815–0650, 41 , 51	00 1210, 1 2		
815–0659, 17			
815–0682, 9			
815–0687, 12			
815–0693, 29 , 34			
815–0721, 31			
815–0760, 14			
815–0800, 33			
815–0820, 34			
821–0004, 34 , 35 , 36			
821–0008, 29 , 53			
821–0009, 41			
821–0010, 17 , 29 , 33			
821–0013, 26 , 37			
821–0014, 12			
821–0016, 29			
821–0018, 37 , 38 , 51			
850–0030, 20			
850–0040, 29			
850–0045, 12 , 53			
850–0050, 42 , 53			
850–0055, 42			
851–0029, 7 , 41			
853–0013, 9 , 17 , 20			
854–0010, 17			
862–0001, 41			



Onan Corporation 1400 73rd Avenue N.E. Minneapolis, MN 55432 1-800-888-ONAN 612-574-5000 International Use

Telex: 275477 Fax: 612-574-8087

Onan is a registered trademark of Onan Corporation